
FAIRBANKS® SCALES



AXLESURANCE SLOW SPEED IN-MOTION VEHICLE WEIGHING SYSTEM

Precheck vehicle weights for highway travel and ensure load balance with Fairbanks AxleSurance. This economical scale system is ideal for any operation concerned with highway safety, vehicle rollover prevention, or inventory reporting.

AXLESURANCE

SLOW SPEED IN-MOTION VEHICLE WEIGHING SYSTEM







• Save Time & Money • Eliminate Overload Risk • Improve Inventory Reporting

xleSurance is an easy-to-install and easy-to-use slow-speed axle weighing system that reduces install time, requires less real estate, and speeds weighing operations, when compared to traditional static truck scales. It is specifically designed as a more affordable option for vehicle weighing customers who do not have the space or need for a traditional full-size truck scale.

While not commercially approved, the AxleSurance system meets NTEP standards and is a worthy investment for safety-conscious customers who want to ensure that their company trucks are not at risk for highway overload or load imbalance. It is also ideal for customers who simply want to better manage inventory.

The AxleSurance system provides axle and gross truck weights



that can be displayed, printed and saved for easy record keeping and reporting. AxleSurance is offered by Fairbanks as a complete vehicle weighing system that contains all the primary components

needed for slow-speed, in-motion checkweighing, including software customized for farm, aggregate or base (other) applications.

AxleSurance works best at a consistent speed of 3 mph and will calculate, display and capture individual axle weights as a truck rolls over the weighbridge. The system sums the weights and prints both individual and gross weight results on each ticket. Tare weights can be prestored into a database or recorded with an in/out operation.

What is included in a Fully-loaded AxleSurance Package?

The package includes all the primary components of the AxleSurance System shown at right, plus all required data cables. (AxleSurance primary components are also sold separately and other module sizes are available for custom configurations.)









11' Precast Scale Module

Outdoor Console with integral Instrument, Printer, Traffic Lights

Remote Display

Remote Key FOB Truck ID System

Information Management Software (Reporting)

Installation Recommendations: AxleSurance In-Motion Weighing System





Minimum approach = Length of truck Optimal speed Max 0.5% 3 MPH (5km/h) 10' (3m) 00 gravel gravel 80' (25m) 80' (25m)

Ideal for agribusiness, dairy and aggregate operations.









AxleSurance Vehicle Weighing Advantages

1 Precast Weighing Module

- Lower cost vehicle weighing solution.
- · Requires less real estate and is easy to install.
- · Certified Patterson lifting points on the platform and weighbridge.
- Entire scale is semi-portable and can be moved from site to site.
- Durable 5000 psi precast platform structure.



Accuracy and Performance 2

- Better than 0.5% accuracy (on average) with proper use and installation.
- Efficiently track profits and inventory movement to improve ROI.
 - · Capture individual axle weights and gross vehicle weight before entering public roads.






- · Precast unit can be set in place with a backhoe or a small crane.
- A minimum 12" bed of compacted flat and level CA6 crushed limestone provides lasting support for the module.











 Concrete approaches are recommended for maximum scale accuracy and can be poured during installation.









Service 4

date	time	printid	truck.id Tru	uck gross	Net	farm	farm.field	farm.variety	moisture
3/18/2018	13:35:24	15	1 TR	UCK 1 44600	500	FARM 1	FIELD 1	P104	55
3/18/2018	13:35:54	16	8 TR	UCK 8 44540	39040	FARM 1	FIELD 1	P104	55
3/18/2018	13:36:24	17	2 TR	UCK 2 34600	12600	FARM 1	FIELD 1	P104	55
3/18/2018	13:36:47	18	2 TR	UCK 2 44600	22600	FARM 2	FIELD 2	P104	35
3/18/2018	13:37:07	19	8 TR	UCK 8 66820	61320	FARM 2	FIELD 2	P104	35
3/18/2018	13:38:19	20	9 \$/,	/+B 44600	38200	FARM 2	FIELD 2	P104	35
3/18/2018	13:38:51	21	8 TR	UCK 8 44600	39100	FARM 3	FIELD 1	P104	21
3/18/2018	13:39:26	23	3 TR	UCK 3 0	64340	FARM 3	FIELD 1	P104	21

AxleSurance Information Management Software

AxleSurance software is available in three formats: Farm, Aggregate and Base. The preferred software format is chosen during startup procedures. Each format offers full customization. With prestored tares, customers can ID and weigh trucks via a

one-pass system. If tare weights need to be established, two passes are required. Axle weights, truck ID, and other variables are captured, printed for the driver, and stored as a CSV file for future analysis/ import into the customer's ERP system.

AXLESURANCE

SLOW SPEED IN-MOTION VEHICLE WEIGHING SYSTEM

Weighing Solutions for the World Since 1830

Fairbanks.com

SPECIFICATIONS

System components	
Fully-loaded AxleSurance	Electronics
Package	Operating environment Temp 5° F to 140° F (-15° C to 60° C) Humidity < 90% non-condensing Display
Capacity	kle display areas and LED backlighting:
Display resolution 20 lbs (10 kg)	Primary display for axle weights 6 x 1.12" (15.2 x 2.8 cm) high digits,
Dynamic accuracy Meets NTEP Class IIIL maintenance tolerance on average (with full-length concrete approaches)	Secondary display for total weight 9 x 0.7" (22.8 x 0.18 cm) high digits
Static accuracy Meets Handbook 44 Class IIIL acceptance tolerance	CalibrationFactory calibration of load cells and instrument, dynamic scaling factor to compensate for sloped
Operating speeds	driveways (only use in one direction) Serial outputs
Static overload	Battery backed clock/calendar Battery life 10 years minimum Additional communications options* Module RS232/RS232 Module RS232/RS485
Precast scale module	Module RS485/RS485
Module dimensions	
Weighbridge dimensions 11' x 2.5' x 5" (3.4 m x 0.76 m x 0.125	
Weighbridge weight	Site requirements
Load cell	ally approach is recommended.
sealed, stainless steel, hermetically s IP68 ingress protection, M12 watertight connectors	approach on either side of the scale is recommended.
Load cell assembly Outboard, in-tension cradle, self-cont	scale is not required but will improve accuracy.
	Foundation

Your Fairbanks Scales Authorized Representative is:

Call toll-free for the representative nearest you:

(800) 451-4107

Call between 8:00 a.m. – 5:00 p.m. Central Time
Corporate Offices: 821 Locust • Kansas City, MO 64106 • (816) 471–0231
Internet Address: http://www.Fairbanks.com

