



# Portable Utility Scale

## 1155 SERIES SCALE WITH THE FB2255 INSTRUMENT



## **AMENDMENT RECORD**

# **Portable Utility Scale Model 1155 With FB2255 Instrument**

## **Document 51315**

Manufactured by Fairbanks Scales Inc.  
821 Locust  
Kansas City, Missouri 64106

Created	02/13	
Revision 1	02/13	Released new product
Revision 2	02/15	Updated parts list
Revision 3	10/16	Updated parts, assembly instructions
Revision 4	02/18	Updated parts list
Revision 5	04/19	Updated parts

## **Disclaimer**

Every effort has been made to provide complete and accurate information in this manual. However, although this manual may include a specifically identified warranty notice for the product, Fairbanks Scales makes no representations or warranties with respect to the contents of this manual, and reserves the right to make changes to this manual without notice when and as improvements are made.

It is the responsibility of the requesting party to develop, maintain, install, and connect networking devices and general network connectivity as it applies to the originating party's network. No warranty or guarantee, expressed or implied, concerning the network, its design, its installation, or operational characteristics has been offered by Fairbanks Scales. Fairbanks Scales shall not be liable for any loss, damage, cost of repairs, incidental or consequential damages of any kind, whether or not based on express or implied warranty, contract, negligence, or strict liability arising in connection with the design, development, installation, or use of an intended network.

**© Copyright 2013-2019**

This document contains proprietary information protected by copyright. All rights are reserved; no part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without prior written permission of the manufacturer.

---

# Table of Contents

---

<b>SECTION 1: GENERAL INFORMATION .....</b>	<b>6</b>
1.1. Introduction.....	6
1.2. AC Power Settings.....	7
1.3. DC Power.....	8
1.4. Specifications .....	9
1.4.1. Instrument Approvals.....	9
1.4.2. Basic Specifications.....	9
1.4.3. Standard Settings .....	9
1.4.4. Weight Accumulator.....	9
1.4.5. Outputs .....	10
1.4.6. PC2255.....	10
1.4.7. Power Requirements .....	10
1.4.8. Out of Range Warnings .....	10
1.4.9. Environment.....	10
<b>SECTION 2: ASSEMBLY .....</b>	<b>11</b>
2.1. Necessary Tools .....	11
2.2. Wheel & Pillar Assembly .....	11
2.3. Mounting Bracket Kit Assembly .....	12
2.4. Loadcell Connections.....	14
2.5. Instrument Wiring .....	14
2.5.1. JP3 Jumper Configuration).....	15
2.5.2. TB2 Load Cell.....	16
2.5.3. TB3 Wiring connections, AC Input.....	16
2.5.4. TB4 Wiring connections, COM1 (A), COM2 (B), and COM2 (C).....	16
2.5.5. TB5 Remote Switch Inputs .....	17
2.5.6. Remote Display Active Keys.....	17
2.6. Installing the Instrument .....	18
2.7. Battery Installation.....	19
<b>SECTION 3: PROGRAMMING .....</b>	<b>20</b>
3.1. Powering On and Off the FB2255 .....	20
3.2. Entering Program Mode .....	20
3.3. Saving Program Changes .....	20
3.4. Setup Menu Programming Parameters .....	20
3.4.1. Setting and Programming Time.....	21
3.4.2. Programming the Date.....	21
<b>SECTION 4: USER OPERATIONS .....</b>	<b>22</b>
4.1. Front Panel Key Functions.....	22
4.2. Operating Procedures .....	23
4.3. Gross, Tare and Net Weight .....	23
4.4. Basic Weighing .....	24
4.5. Gross Weighing .....	24
4.6. Net Weighing.....	24
4.7. Gross/Tare/Net Weighing .....	25



<b>SECTION 5: PARTS.....</b>	<b>26</b>
<b>5.1. 1155 Series.....</b>	<b>26</b>
5.1.1. <i>Parts List</i> .....	26
5.1.2. <i>Parts Diagram</i> .....	29

---

# Section 1: General Information

---

## 1.1. INTRODUCTION

The **1155 Series Scale** is a combination of a roll-around cast-iron base and a battery/AC powered digital indicator. NTEP and MC approved for “**Legal for Trade**” applications.


## APPLICATIONS

- Material handling
- Inventory management
- Parts distribution
- Warehousing
- Auditing
- Bag filling

The **1155 Portable Platform Scale Base** is constructed of cast iron with cast iron levers.

- The weight display is an AC/Battery powered **FB2255 Series Indicator**.
- It is equipped with communication ports for connecting printers, displays, and/or computers.
- The scale is rated at **1000 pounds** capacity.
- The interval, or graduation size is 0.2 pounds.

Although the unit is factory calibrated, some assembly is required.



## WARNING!

*The 1155's shipping weight is approximately **185 pounds**.  
Use caution to prevent personal injury and/or damage to the product when  
lifting or moving it.*

---

**NOTE:** *For commercial weighing applications, the scale must be 'placed-in-service' by a licensed scale technician.*

*For product solutions, please call **FAIRBANKS SCALES TECHNICAL SERVICES.***

---

Power supply must be used with a correctly **grounded** outlet.

- Place the scale on a solid and level floor.
- Avoid extremes in temperature, humidity, shock, moisture and dust.
- The scale is factory calibrated and supplied ready to be assembled and used.
- The **1155 Series Scale** must be serviced a by qualified technician.
  - *Failure to do so may void all implied and/or written warranties.*
- Ensure that no shipping damage has occurred to any of the equipment.
  - *Damage to the shipping carton must be noted by the receiving party.*
  - *Damage must be made known to the shipper.*
  - *Claims for shipping damage are made by the receiving party to the shipper.*
- It is the customer's/owner's responsibility to maintain the scale in good operating condition, and to protect the scale from accidental damage.

A rectangular warning box with a thick border of alternating black and yellow diagonal stripes. Inside the box, the word "ATTENTION!" is written in large, bold, red capital letters.

## **A T T E N T I O N !**

**DO NOT** *pack or ship an instrument with batteries installed.*

*If batteries are expected to be left for an extended period of non-use, remove them all from their holder.*

## 1.2. AC POWER SETTINGS

### 110VAC


The FB2255 is designed to operate from **80 to 260 volts AC, 50 to 60 HZ.**

- 110 VAC operations.
- The Instrument is factory wired for 110 VAC and requires a three prong grounded outlet.

### 220 VAC

The FB2255 has **AUTO SWITCHING** capabilities.

- Rewire the power Cord according to the diagram.



## 1.3. DC POWER

Batteries	Five (5) Size “D” Alkaline batteries @ 1.5 Volts DC each.
Battery Life	<ul style="list-style-type: none"> <li>• Up to forty (40) Hours or greater with a maximum load of 4, 350 load cells and backlighting enabled.</li> <li>• Battery usage time can be adversely affected by battery storage, battery capacity and battery brand.</li> <li>• To maximize battery life, Serial Ports 1 and 2 should be switched <b>OFF</b> if not used.</li> </ul>
Internal Battery	<ul style="list-style-type: none"> <li>• Should be replaced every 12 months using Panasonic CR 1220 3V or equivalent.</li> </ul>





## 1.4. SPECIFICATIONS

### 1.4.1. INSTRUMENT APPROVALS

CC	09-023
MC	AM-5720
ETL	ETL Listed
Conforms to ANSI/UL STD 60950-1	
Certified to CAN/CSA C22.2 STD NO. 60950-1-03	

### 1.4.2. BASIC SPECIFICATIONS

ENCLOSURE	ABS, Black NEMA 1
DISPLAY	6-digits, One inch (1") LCD, Green Backlight
FRONT PANEL KEYS	On/Off, Units, Zero, B/G, Net, Tare and Print
UNITS	lb, oz, kg, g and lb/oz, or custom
GRADUATION SIZE	0.0001 to 50
AD CONVERSION	66 per second
LOAD CELL EXCITATION	5 Volts DC
SENSITIVITY	1 $\mu$ v/d (microvolt/division)
LOAD CELLS	Eight (8) 350 ohm or Sixteen (16) 1000 ohm
DISPLAYED DIVISIONS	10,000d Commercial and 100,000d Non-Commercial
CAPACITIES	Programmable to 999999

### 1.4.3. STANDARD SETTINGS

Zero Range	Off, 2 % or 100%
Auto Zero Tracking	OFF, 0.5, 1 or 3 divisions
Balance	OFF, 0.5, 1 or 3 divisions
Filter	Slow, Animal, Standard, and Fast
Display Update Rate	0.2, 0.4, and 0.8 seconds

### 1.4.4. WEIGHT ACCUMULATOR

Capacity	999,999 Weight Units – Printed or viewed.
----------	--



## 1.4. SPECIFICATIONS, CONTINUED

### 1.4.5. OUTPUTS

PORT 1	Bidirectional Serial Port. Settings include <b>OFF</b> , <b>RS232</b> , and <b>RS485</b> . RS232 has 30+ updates a second
PORT 2	Port 2 is used to interface to the <b>PC2255</b> program, OR, Provide <b>20 mA passive</b> , <b>RS 232</b> , or <b>RS 485</b> .

### 1.4.6. PC2255

- Computer software utility program is available for download using the Fairbanks Intranet.
- PC2255 is required for setting certain aspects of programming, such as custom Units and custom ticket formatting.

### 1.4.7. POWER REQUIREMENTS

- 117 volts AC +/- 10 %
- 220 volts AC +/- 10 %
- $\leq 0.2$  volts AC between Neutral and Ground
- 1.5 watts maximum
- The FB2255 is designed to operate from 80 to 260 volts AC, 50 to 60 Hertz

### 1.4.8. OUT OF RANGE WARNINGS

HiCAP	Scale input is over capacity
- - - - -	Displayed weight exceeds 6 digits


### 1.4.9. ENVIRONMENT

Temperature	-10°C to + 40°C (+14°F to + 104°F)
Storage Temp.	-40°C to + 60°C (-40°F to + 140°F)



## 2.2. WHEEL & PILLAR ASSEMBLY, CONTINUED


11. Screw the two (2) **pillar rods (#1)** into the two (2) tapped holes of the base.
12. Place the **pillar (#2)** over the pillar rods.
  - The cutouts face to the left and right of the platform
13. Insert the **steelyard rod (#35)** down through the pillar.
  - The bent hook is on top, and the loose swivel hook is on the bottom.



## 2.3. MOUNTING BRACKET KIT ASSEMBLY


**NOTE:** The Adapter is partially assembled and packed with bubble-wrap. The **ADAPTER BRACKET (#77)**, **STIFFENER PLATE (#78)**, and **LOAD CELL MOUNTING PLATE (#72)** are in correct orientation within the box.

1. Lift the entire mounting bracket kit out of the box and remove the bubble-wrap.
2. Allowing the load cell linkage assembly to go through the hole and the **load cell plate (#72)**, set it flush on top of the **stiffener plate (#78)**.
3. With the slot in the back (as viewed from the platform), place the assembly on over the **two pillar rods** so it rests on top of the **pillar**.
  - Ensure that the mounting bracket is setting flush and aligned.
  - Looking up from the bottom of the mounting bracket, there are two (2) small studs in opposite corners on the **inside** of the pillar.
4. Fasten the two (2) **pillar rods** to the **top of the pillar** with the two (2) washers and nuts.




## 2.3. MOUNTING BRACKET KIT ASSEMBLY, CONTINUED

5. Tighten the pillar rod nuts.
  - **Do not** touch the load cell while tightening.
6. On the bottom back-side of the scale's base, lift up the **lever end** while placing the hook under the lever's pivot.
  - Do this while holding the hook on top of the pull rod.
7. Inserting the "S" hook:
  - a. Insert the "S" hook (#73) through the eyelet of the load cell linkage cable adapter.
  - b. Slide the "S" hook **bottom** into the top hook on the **Steelyard rod**.




## 2.4. LOADCELL CONNECTIONS



1. Remove the screws on the back cover of the Indicator to access the main printed circuit board inside the enclosure.
  - Use caution to avoid pulling cables out of their connectors.
2. Bring the dressed end of the load cell cable through the strain relief connector on the back of the instrument, allowing enough cable on the inside to reach the load cell connection terminal on the main board.
3. Tighten strain relief as needed to grip the load cell cable.
4. Replace and refasten the back onto the Indicator.


## 2.5. INSTRUMENT WIRING

INSTRUMENT	COLOR CODE	LOAD CELL
TB2 - 1	Black	(-) EXC
TB2 - 3	Green	(+) EXC
TB2 - 7	White	(+) SIG
TB2 - 8	Red	(-) SIG





## 2.5. INSTRUMENT WIRING, CONTINUED



### 2.5.1. JP3 JUMPER CONFIGURATION)

JP3	RS232	RS485	RS422*	PORT
1-2	Out	120 Ohm Resistor	120 Ohm Resistor	COM1
3-4	Out	In	Out	COM1
5-6	Out	In	Out	COM1
7-8	Out	In	Out	COM2
9-10	Out	In	Out	COM2
11-12	Out	120 Ohm Resistor	120 Ohm Resistor	COM2

\*Port should be set to RS485.

**NOTE: 120 ohm Termination Resistors** are required if the receiver is the last node on the network.

### 2.5.2. TB2 LOAD CELL

TB2	LOAD CELL
1	(-)Excitation 5V
2	(-)Sense
3	(+) Excitation
4	(+) Sense
5	Shield
6	(+) Signal
7	(-) Signal
JP7	(+) Sense Shorting Link
JP8	(-) Sense Shorting Link

### 2.5.3. TB3 WIRING CONNECTIONS, AC INPUT

1	AC	AC Input
2	ACC	ACC Input
3	Ground	AC Ground

### 2.5.4. TB4 WIRING CONNECTIONS, COM1 (A), COM2 (B), AND COM2 (C)

TB4 (A)	RS232	RS485	RS422*	PORT
1	Rx – Receive Data	(-) RS485	RS422 (-) Rx	COM1
2	Tx – Transmit Data	(-) RS485	RS422 (-) Tx	COM1
3	CTS – Clear-to-Send	(+) RS485	RS422 (+) RX	COM1
4	GND -- Ground	GND	GND	COM1
5	RTS – Ready-to-Send	(+) RS485	RS422 (+) Tx	COM1

TB4 (B)	RS232	RS485	RS422*	PORT
1	Rx – Receive Data	(-) RS485	RS422 (-) Rx	COM2
2	TX – Transmit Data	(-) RS485	RS422 (-) Tx	COM2
3	CTS – Clear-to-Send	(+) RS485	RS422 (+) Rx	COM2
4	GND – Ground	GND	GND	COM2
5	RTS – Ready-to-Send	RS485	RS422 (+) Tx	COM2

TB4 (C)	20 MA	RS485	RS422	PORT
1	(+) TX – Remote Display Passive, 20 mA Output			COM2
2	(-) TX – Remote Display Passive, 20 mA Output			COM2
3	(+) 7.5V Bluetooth® Technology Supply			

\*Port should be set to RS485.



### **2.5.5. TB5 REMOTE SWITCH INPUTS**



1	Ground	
2	Ground	
3	Ground	
4	Print	Connect to ground to perform programmed Print function
5	Tare	Connect to ground to Tare off Gross weight
6	B/G Net	Connect to ground to Select Gross/Tare displays
7	Zero	Connect to ground to Zero Platform Weight
8	Units	Connect to ground to change to alternate weight units

### **2.5.6. REMOTE DISPLAY ACTIVE KEYS**

<b>INSTRUMENT</b>	<b>FB2255 ACTIVE FRONT PANEL KEYS</b>
<b>FB2200</b>	No Active Keys
<b>FB2255</b>	Units, Zero, Gross Net, Auto Tare, Print
<b>FB2255</b>	Units, Zero, Gross Net, Auto Tare, Print
<b>2300</b>	No Active Keys
<b>2500</b>	No Active Keys
<b>2800</b>	No Active Keys
<b>5200A</b>	Units, Gross Net

## 2.6. INSTALLING THE INSTRUMENT


1. The load cell cable has attached a 4-pin Molex connector.
2. If necessary, wire the 24" ribbon cable (P/N 22706) to the instrument per wiring diagram. Opposite end of cable has mating 4-pin Molex connector.
3. Gently slide the connectors together until they snap in place.
4. Bundle excess load cell cable using the cable tie so it does not contact the load cell or become damaged.



5. Place the instrument on top of the mounting bracket with the keypad/display facing the scale platform.
6. Remove the rubber feet on the bottom of the FB2255's tilt bracket.
7. Fasten the instrument to the mounting bracket using the four (4) screws, washers, lock washers and nuts (*as shown*).

## 2.7. BATTERY INSTALLATION

1. Loosen the Indicator positioning knobs (located at each side), and then rotate the unit forward to access the back **Battery (ABS) Enclosure**.
2. Unscrew the two large knurled screws on the back of the Instrument
3. Remove the battery cover.
4. Insert **five (5) alkaline “D” cell batteries**.
  - Industrial ‘D’ size Energizer EN95 battery or equivalent is recommended for maximum operating time.
5. Refasten the back cover and tighten the knurled screws.
6. Reposition the indicator and tighten back the knobs.



---

## Section 3: Programming


---

### 3.1. POWERING ON AND OFF THE FB2255

- To **turn on** the FB2255, press and hold the **ON / OFF Key** for two (2) seconds.
  - The Instrument will display “888888”, then a “1234567890” character display moving from right to left, followed by the revision of software.
  - Upon completing the warm-up, the FB2255 will display the actual weight on the scale.
- To **turn off** the FB2255, press and hold the **ON / OFF Key** for two (2) seconds.

### 3.2. ENTERING PROGRAM MODE

Unscrew the plastic lockout plug located at the rear of the enclosure and press the **Internal Program Switch**.



---

**NOTE:** Repeatedly pressing the program switch will cycle through **Set-up**, **Config**, **APP**, **CAL**, and back to the **Weigh Mode**.

*If the program parameters are outside of set limits, the **Program Defaults** are loaded/reloaded at power-up.*

---

### 3.3. SAVING PROGRAM CHANGES

- Program changes are automatically saved upon exiting the **Program Mode**.
- Press the **PROGRAM SWITCH** to exit to the **Weigh Mode**.

### 3.4. SETUP MENU PROGRAMMING PARAMETERS

1. Press and hold the **Internal Program Switch** until **SETUP** displays.
2. Use the right arrow key to scroll through each menu item.
3. Program the **Set Time**, **Set Date** and **Port 1** functions, as shown in the following information.

### 3.4.1. SETTING AND PROGRAMMING TIME

4. At **SetUP**, press the **RIGHT ARROW** key **Set-ti** displays, followed by the current setting in **HHMMSS**.
5. Press the **MENU** key.
6. Key the new time setting with the **0-9** keys.
7. Press **ENTER**.
8. At the “**12hr A**” prompt, press the **MENU** key.
9. Use the **ARROW KEYS** to toggle through the option noted below.
  - **12hr A** – 12 hour clock, currently AM.
  - **12hr P** – 12 hour clock, currently PM.
  - **24 hour** – Military time (1:00 PM = 1300 hours).
10. Press **ENTER** to save the setting.

### 3.4.2. PROGRAMMING THE DATE

- **Set-dA** displays, followed by the current date setting.
  - Date is entered in the **MM-DD-YY** format.
11. Press **Menu**.
    - The first digit will blink.
  12. Key the new date setting with the **0-9** keys.
  13. When complete, the program will advance to Port 1.
  14. Press the **INTERNAL PROGRAMMING SWITCH** four (4) times slowly, and the instrument will return to the **Weigh Mode**.

---

## Section 4: User Operations

---

### 4.1. FRONT PANEL KEY FUNCTIONS

**NOTE:** Installing a jumper at **J6**, located at the upper-right corner of the main **PCB Assembly**, will disable the **ON/OFF switch**.

*This is **not recommended** in battery powered applications.*

---

KEY	FUNCTION
ON/OFF	Turns the Instrument on or off.
UNITS	Switches between pre-programmed selectable weight units.
ZERO	Sets the display to zero, programmable: 2% or 100% of capacity.
B/G – NET	Toggles between Gross and Net weights <ul style="list-style-type: none"><li>This applies only if a Tare Value has been entered greater than ZERO.</li></ul>
TARE	Automatically tares off displayed weight when key is pressed.
PRINT	Simple RS232 output when key is pressed.
0-9	Used for Programming and inputting manual tares.
MENU	Gains access to the sub-menus in the <b>Configuration Mode</b> .
ARROW KEYS	Used for scrolling through the menu selections.

Depending on programmed selection, **Tare Weight** amount will do one of the following.

- Be retained for reuse until changed, or if power is removed.

OR...

- Automatically clear when **Gross Weight** returns to **ZERO**.



## 4.2. OPERATING PROCEDURES


- The **Zero**, **Tare** and the **AZT** functions require the displayed weight to be stable before these functions will operate.
- The weight reading is stable if the variation in weight is less than the programmed **MOTION BAND**.

## 4.3. GROSS, TARE AND NET Weight

There are three terms used when weighing an object's or load's amount.

The **NET WEIGHT** (*product only*) is the **GROSS WEIGHT** (total amount) minus the **TARE WEIGHT** (*container only*).

$$\text{NET WEIGHT} = \text{Gross Weight} - \text{Tare Weight}$$



### WORKING EXAMPLE

A full can of house paint is an object to be weighed. The empty can is the **TARE** weight. The paint is the **NET** weight. Together they equal the **GROSS** weight.

## 4.4. BASIC WEIGHING

*Follow these steps for Basic Weighing.*

1. Empty the platform.
2. Turn the scale **ON**.
3. Press **ZERO**.
  - When the display indicates “0”, it is ready for use.

## 4.5. Gross Weighing

*Follow these steps for Gross Weighing.*

1. Press the **GROSS/NET** key, if required, to set display to GR (gross).
2. Press the **ZERO** key, if required, to set scale to “0”.
3. Place the container/object on the scale (Tare weight).
4. Read the **Gross Weight** on the display.

## 4.6. Net Weighing

*Follow these steps for Net Weighing.*

1. Press the **GROSS/NET** key, if required, to set display to GR (gross).
2. Press the **ZERO** key, if required, to set scale to “0”.
3. Place container/object on scale (Tare weight).
4. Press the **TARE** key.
5. Place material in container or add objects (Net weight).
6. Read the **Net Weight** on the display.





## 4.7. GROSS/TARE/NET WEIGHING

1. Press the **GROSS/NET** key to display **GR** (Gross).
  2. Press the **ZERO** key, if required, to set scale to “0”.
  3. Place container/object on scale, noting the weight.
  4. Press **TARE**.
  5. Place material in container or add objects.
  6. Note the **Net Weight** on the display.
  7. Press the **GROSS/NET** key to switch to **Gross**.
- Read the **Gross Weight** on the display.

---

## Section 5: Parts


---

### 5.1. 1155 SERIES

#### 5.1.1. PARTS LIST

Item(s)	Part NO.	Description
1	95850	PILLAR ROD, (SHORT)
2	58933	PILLAR
3	95847	PLATFORM COVER
4	95848	FRAME
5	95855	COTTER PIN
6	58937	BEARING, PLATFORM
7	95856	SCREW, PH HD
8	95857	SCREW, ALLEN
9	95858	LEVEL, BUBBLE
10	95859	PIN, CORNER LOP
11	71623	LOOP, CORNER
12	71624	BEARING, CORNER Loop
13	71625	COTTER PIN
10,11,12,13	58938	LOOP, CORNER ASSY
14	95867	HEX NUT
15	95868	HEX HEAD BOLT
16	95869	WHEEL, 5" DIAMETER
17	71627	COTTER PIN
18	71629	WASHER, FLAT
19	71630	AXLE
24	95861	PIVOT, LOAD & FOLCRUM
25	72948	SHORT LEVER ASSY
26	58939	CENTER CONNECTION ASSY
31	95863	CENTER PIVOT, LONG LEVER
33	72947	LONG LEVER ASSY
34	95864	LONG LEVER TIP PIVOT


<b>35</b>	168302	STEEL YARD ROD ASSY
<b>44</b>	71592	ACORN NUTS (2)
<b>61</b>	95865	PLATFORM LOCKING PIN
<b>62</b>	95866	COTTER PIN, PLATFORM LOCKING PIN
<b>71</b>	35341	Load cell assembly
<b>72</b>	14237	Plate, mounting
<b>73</b>	12643	“S” hook
<b>75</b>	17617	Mount, cable tie
<b>76</b>	17613	Tie, wire
<b>77</b>	20176	Bracket
<b>78</b>	26299	Handle assembly
<b>79</b>	11263	Clip, cable
<b>80</b>	13182	Screw, cap, socket head M4 x .25
<b>81</b>	11119	Washer, plain-flat #10
<b>82</b>	11189	Washer, lock extension tooth spring #10
<b>83</b>	11003	Nut-hex 10-32
<b>84</b>	11076	Screw, cap, hex head, 10-32 x .75
<b>85</b>	15716	Nut, threadlock acorn, 10-32
<b>88</b>	35145	Plate, Mount, universal instrument to line scale
<b>99</b>	30047	Instrument assembly with battery installed FB2255 ABS
<b>90</b>	34971	Manual card (26461)
<b>91</b>	13584	Shim
<b>92</b>	14342	Spacer, load cell
<b>93</b>	13099	Linkage, cable
<b>94</b>	17579	Spacer, 8-32 threads x .38 lg
<b>95</b>	22706	Cable assembly, W1
<b>98</b>	17626	Clip, plastic




### 5.1.2. PARTS DIAGRAM




(Figures: 5-2, 5-3, 5-4, 5-5 and 5-6)

**Figure 5-2**



**Figure 5-3**



**Figure 5-4**

**Figure 5-5**

**Figure 5-6**




Manufactured by Fairbanks Scales, Inc.  
821 Locust Street  
Kansas City, MO 64106

[www.fairbanks.com](http://www.fairbanks.com)

# Portable Utility Scale

**Model 1155 Series  
FB2255 Instrument**

**Instructional Manual  
Document 51315**