




Operator Manual

FB6000 Series Instrumentation

FB6001 In/Out/ GTN Analog Desktop Instrument

FB6002 In/Out/ GTN Analog NEMA 4X Wall Mount Instrument

FB6003 In/Out/GTN Analog Panel Mount Instrument





Disclaimer

Every effort has been made to provide complete and accurate information in this manual. However, although this manual may include a specifically identified warranty notice for the product, Fairbanks Scale makes no representations or warranties with respect to the contents of this manual, and reserves the right to make changes to this manual without notice when and as improvements are made.

Fairbanks Scale shall not be liable for any loss, damage, cost of repairs, incidental or consequential damages of any kind, whether or not based on express or implied warranty, contract, negligence, or strict liability arising in connection with the design, development, installation, or use of the scale.

© Copyright 2020

This document contains proprietary information protected by copyright. All rights are reserved; no part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without prior written permission of the manufacturer

Public License Statement

Copyright © 2020, Fairbanks Scales, Inc.
All Rights Reserved

THE FAIRBANKS SCALES COMPANY DEVELOPED SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The software included in this [Fairbanks Scales, Inc.](#) product includes one or more open source software components. This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org>). This product also includes software licensed under the Apache License and you may not use any of these files except in compliance with the Apache License. A copy of the Apache License may be obtained at <http://www.apache.org/licenses>. This product may also include the applications governed by the Zlib license, LibPNG license, and the MIT license. For a listing of the open source software applications included in the product that are governed by any one of the above identified licenses, please contact Fairbanks Scales, Inc. at the address provided below.

To the extent applicable, Fairbanks Scales, Inc. will comply with the required disclosure conditions set forth in each of the open source software licenses identified below.

GNU PUBLIC LICENSE:

This Fairbanks Scales, Inc. product includes open source software components governed by the GNU Public License. To the extent applicable, the person in possession of this product may request a copy of the source code of the software included in the product that is covered by the GNU Public License. The possessor of this product may request such a copy by contacting [Fairbanks Scales, Inc.](#) at the address set forth below. A copy of the GNU Public License may be found at <http://www.gnu.org/licenses/gpl.html>.

GNU LESSER GENERAL PUBLIC LICENSE (LGPL):

This Fairbanks Scales, Inc. product includes open source software libraries governed by the LGPL. The use of the open source libraries is governed by the LGPL and copies of the source code of these libraries may be obtained by contacting [Fairbanks Scales, Inc.](#) at the address set forth below. A copy of the LGPL license may be found at <http://www.gnu.org/copyleft/lesser.html> and a copy of the GNU Public License incorporated into the LGPL is found at the link provided above.

BSD LICENSE:

This Fairbanks Scales, Inc. product includes open source software governed by the BSD open source license. Your own redistribution and use in source and binary forms of these Applications, with or without modification, are permitted provided that the following conditions set forth in the BSD license are met, including:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

A copy of the BSD license may be found at <http://opensource.org/licenses/BSD-2-Clause> or <http://opensource.org/licenses/BSD-3-Clause>.

ARTISTIC LICENSE:

This Fairbanks Scales, Inc. product includes open source software governed by the Artistic License. To the extent applicable, the person in possession of this product may request a copy of the source code of the portions of the product software that are covered by the Artistic License or you may find copies of these open source code applications at [\[www.cpan.org\]](http://www.cpan.org) [Fairbanks to verify location at which user can download source code]. To request a list of the applications and copy of the source code by contacting Fairbanks Scales, Inc. at the address set forth below. A copy of the Artistic License can be found at <http://opensource.org/licenses/artistic-license-2.0>.

Any Open Source Software inquiries to Fairbanks Scales, Inc. shall be sent to: [Fairbanks to provide contact (either person or the title) and the mailing address.] Any request for copies of the source code will only be provided as required by the license under which the open source component was used. For any copies of source code provided, a small processing fee of **\$15.00** may apply to cover the cost of the storage medium and the time required for reproduction.

AMENDMENT RECORD

FB6000 Series Instrumentation

FB6001 IN/OUT/ GTN Analog Desktop Instrument (**31675**)

FB6002 IN/OUT/ GTN Analog NEMA 4X Wall Mount Instrument (**32575**)

FB6003 IN/OUT/GTN Analog Panel Mount Instrument (**32675**)

Operator Manual Document 51293

Manufactured by

Fairbanks Scales Inc.

Revision #	Date	Update
Revision 1	12/12	New product documentation release.
Revision 2	01/13	Corrected specification typographical error.
Revision 3	08/14	Numerous programming updates. Added Appendix II: Remote Serial Commands.
Revision 4	07/15	Added Web Interface section
Revision 5	01/16	Updated Appendix 1: data string format, Updated cross-reference links throughout the manual.
Revision 6	06/17	Added TM-U220 printer information
Revision 7	08/17	Updated: Web Interface, removed workflow diagrams, Loop ID
Revision 8	10/17	Updated: Web Interface > Configuration Menu
Revision 9	07/19	Updated: General Information; Appendix III
Revision 10	02/20	Updated: Serial Input/Output section
Revision 11	06/20	Updated: DemandPC subsection
Revision 12	10/20	Updated Standard Ticketing Formatting Steps > added Error Conditions

TABLE OF CONTENTS

SECTION 1: GENERAL INFORMATION	8
1.1. Instrument Description.....	8
1.1.1. Standard Features	8
1.1.2. Accessories	8
1.2. Technical Specifications	9
1.3. Levels of Security	10
1.4. Users' Responsibility	11
SECTION 2: USER OPERATIONS.....	12
2.1. Front Panel Key Functions.....	12
2.2. Startup Procedure.....	13
2.3. Gross Weighing	13
2.4. Basic Weighing	13
2.5. Gross-Tare-Net Weighing.....	14
2.6. Inbound/Outbound Weighing.....	15
SECTION 3: PROGRAMMING OVERVIEW.....	17
3.1. Login.....	17
3.2. Defining the Programming Menus.....	17
3.3. Short-cut Method for Menu Navigations	18
SECTION 4: WEB INTERFACE	19
4.1. How to Connect Remotely to the FB60XX Series:	19
4.1.1. To obtain the current IP address of the FB60XX:	19
4.2. Logging In to the Web Interface.....	20
4.3. Navigating the Web Interface.....	21
4.3.1. Audit Trail	21
4.3.2. Operator Menu.....	22
4.3.3. Configuration Menu	23
4.3.4. Scale Diagnostics	25
SECTION 5: AUDIT TRAIL.....	26
5.1. Display.....	26
5.2. Print	26
5.3. NJ Jumper State.....	27
5.4. SW Revision.....	27
SECTION 6: OPERATOR MENU	28
6.1. New Tare.....	28
6.2. New Keyboard Tare	29
6.3. Tare Delete	30
6.4. Tare Report.....	30
6.5. Time & Date.....	31
6.5.1. Format Time & Date.....	31
6.5.2. Set Time & Date	32
6.6. Tickets	32
6.7. Load Cell Diagnostics	33

6.8. Utility.....	34
6.8.1. <i>Set Display Intensity</i>	<i>34</i>
6.8.2. <i>Key Pad Beep, Set Volume, Mute</i>	<i>34</i>
6.9. Options (Operator).....	35
SECTION 7: CONFIGURATION MENU	36
7.1. Change Customer PW	36
7.2. Prompts – Programmable	36
7.3. Legends – Programmable	37
7.4. Ticket Formats	37
7.5. COM Ports	37
7.6. Threshold Weights.....	38
7.7. Traffic Light Control	38
7.8. Reports	39
7.9. Network IP Settings	40
7.10. Transaction Files	41
SECTION 8: SERIAL INPUT / OUTPUT.....	43
8.1. Printers	43
8.1.1. <i>Printer Switch Settings.....</i>	<i>43</i>
8.1.2. <i>Printer Cabling</i>	<i>43</i>
8.1.3. <i>iDP3550 Tape Printer Settings.....</i>	<i>44</i>
8.1.4. <i>TM-U590 Ticket Printer Settings</i>	<i>44</i>
8.1.5. <i>TM-U295 Ticket Printer Settings</i>	<i>45</i>
8.1.6. <i>TM-U220 Tape Printer</i>	<i>46</i>
8.1.7. <i>SP298 Printer Settings.....</i>	<i>48</i>
8.1.8. <i>SP700 Printer Settings.....</i>	<i>50</i>
8.1.9. <i>SP2000 Printer Settings.....</i>	<i>52</i>
8.1.10. <i>SP2200 Printer Settings.....</i>	<i>52</i>
8.1.11. <i>TM-U230 Printer Settings</i>	<i>53</i>
8.2. COM Ports	54
8.2.1. <i>Programming COM PORTS.....</i>	<i>55</i>
8.2.2. <i>Configuring the Remote Display Output.....</i>	<i>55</i>
8.2.3. <i>Selecting the Printer</i>	<i>56</i>
8.2.4. <i>PC Data String Output.....</i>	<i>57</i>
8.2.5. <i>Configuring Network Output.....</i>	<i>57</i>
8.2.6. <i>DemandPC</i>	<i>58</i>
8.3. 4-20mA Analog Card.....	60
8.3.1. <i>Active 4-20mA Kit Installation (33258)</i>	<i>60</i>
8.3.2. <i>Passive 4-20mA Kit Installation (30919).....</i>	<i>61</i>
8.4. Traffic Light Control	62
8.4.1. <i>Control (Traffic Light)</i>	<i>62</i>
8.4.2. <i>Event to Signal.....</i>	<i>63</i>
8.5. Programming the Remote Display	64
8.5.1. <i>Display Mode</i>	<i>64</i>
8.5.2. <i>Type (Output)</i>	<i>64</i>
8.5.3. <i>Enable 1605T</i>	<i>65</i>
8.6. Basic Troubleshooting	66
SECTION 9: FORMATTING TICKETS.....	67
9.1. Standard Ticket Formatting Steps	67
9.2. Printer and Ticket Differences	68



9.3. Programming Tips	69
9.3.1. <i>Write Commands</i>	69
9.3.2. <i>Quick Formatting Buttons</i>	71
9.3.3. <i>Ticket Format Commands</i>	72
9.3.4. <i>Ticket Formats</i>	73
9.3.5. <i>G/T/N Ticket Formatting</i>	74
9.3.6. <i>Inbound Ticket Formatting</i>	75
9.3.7. <i>Outbound Ticket Formatting</i>	76
9.3.8. <i>Completed Transaction Ticket Example</i>	77
9.3.9. <i>BasicIn and BasicOut Ticket Formatting</i>	78
9.3.10. <i>Deleting a Ticket Format</i>	79
9.4. Formatting Web Interface Tickets.....	79
9.4.1. <i>Logging In to the Web Interface</i>	79
9.4.2. <i>Ticket Format</i>	80
9.4.3. <i>Standard Default Formats</i>	82
9.4.4. <i>Exiting Without Saving</i>	83
APPENDIX I: DATA STRING OUTPUTS	84
A. Remote Display Output	84
B. Configure Output	84
APPENDIX II: REMOTE SERIAL COMMANDS	88
APPENDIX III: CONNECTING TO THE FB60XX VIA ETHERNET	89

SECTION 1: GENERAL INFORMATION

1.1. Instrument Description

The **FB6001/6002/6003 Instrument** has four Operating Modes a Basic, Inbound, Outbound, and GTN instrument.

- The Instrument may be enhanced by adding either a 4-20mA or a Relay Module to the unit.
- Only one (1) module may be added to provide either a 4-20mA output or a Relay Module interface to control traffic lights.

The **FB6001/6002/6003 Instrument** is designed for a wide variety of truck, floor, hopper, and tank scale applications.

The load cells interface with the Instrument through the **Scale Interface Card (SIC)**.

An RS-232 interface allows for the transfer of data from the Instrument to a computer and vice versa.

Noted below are the three FB6000 Series instrument models.

Desktop – FB6001 (31675)

NEMA 4X Wall Mount – 6002 (32575)

Panel Mount – 6003 (32675)

1.1.1. Standard Features

- | | |
|--|--|
| -0.8" LED alphanumeric display | -Three (3) RS232 serial ports |
| -One (1) Ethernet Port | -Capable of formatting tickets |
| -Three (3) USB Ports | -Keypad Buttons, including the following: |
| -Choice of either One (1) 4-20mA port or one (1) Analog Relay Board. | -0-9 keys, Enter, Red (stop), Green (go), Tare, In, Out, Units, B/G/Net, Zero and Print. |
| -External Display COM Port 4 | |

1.1.2. Accessories

PART NO.	DESCRIPTION
30919	4-20mA Analog Kit *
30920	Relay PCB Assy Kit *
25498	Mini USB Keyboard (87 key)
31036	Standard USB Keyboard (104 key)
15892	SVP/ Uninterruptable Power Supply

* Only one or the other of these accessories may be used in the FB6001/02/03 series instrument.

1.2. Technical Specifications

PARAMETER	SPECIFICATION
Model	Desktop FB6001; NEMA 4X Wall Mount FB6012; Panel Mount FB6013
Load Cell Interface	Up to 16 ~ 1000Ω load cells max, Or up to 8 ~ 350Ω load cells max
Cell Capacity	1 thru 999,999
Cell Units	lbs, kgs, tons, tonne
No. of Scales	One (1) only
Resolution	10000d commercial 20000d non-commercial
Scale Capacity	100-999,999
Division Size	0.0001 thru 50
Units	lbs, kgs, tons, tonne
Serial Input/ Output	Three (3) RS232 COM Ports, one (1) Console Port, three (3) USB Ports
Storage	Up to 100,000 transactions
Auto Zero Tracking	Selectable – Off, 0.5d, 1.0d, 3.0d
Motion Band	Selectable – Off, 0.5d, 1.0d, 3.0d
Zero Range	Selectable – 2%, 100%

ENVIRONMENTAL	SPECIFICATION
Enclosure	NEMA 12 desk mount and Panel mount; NEMA 4X wall mount
Operating Temperature	14°F to 104°F, (–10°C to 40°C).
Operating Humidity	NEMA 12 non-condensing, not suitable for wash-down conditions.

POWER REQUIREMENTS	SPECIFICATION
Incoming Voltage Requirement	Instrument has an Auto-switching power supply. 100 VAC to 130 VAC, 50Hz\ 60Hz 200 VAC to 260 VAC, 50Hz\ 60Hz It is recommended to install a separate circuit from the circuit panel to the outlet used. There must not be more than 0.2VAC between AC neutral and ground
Ground Requirements	For proper performance, the ground should have no more than 3.0 Ω resistance to true earth ground.
Power Consumption	Less than (<) 40 watts
ETL Listed	Conforms to UL STD 60950-1. CAN/CSA C 22.2 NO.60950-1-03.
Approvals	CC# 12-099 MC# AM-5878

1.3. Levels of Security

There are three security levels for accessing the FB6001/2/3 programs.

Security Levels One thru Three (1 – 3) configures the hierarchy of the management functions, and limits privilege accesses from unauthorized employees.

When making the employee hierarchy, employee duties should determine their security level.

Each access level includes all of the rights of any access level(s) below it.

FIRST LEVEL: OPERATOR ACCESS

- Accesses the Operator Menu and the Audit Trail Menu.
- **No Password** is necessary for this level of instrument access.

SECOND LEVEL: SUPERVISOR ACCESS

- All of the Operator Access privileges.
- Supervisor Password is required.
- The *default first time use* password for the **Supervisor Access** is **“1”**.

It is strongly recommended to change this password.

- Second Level Users can also access the **Configuration Menu**.

THIRD LEVEL: SERVICE TECHNICIAN ACCESS

- Service Technician privileges to install and program the Instrument.

1.4. Users' Responsibility

All electronic and mechanical calibrations and/or adjustments required for making this equipment perform to accuracy and operational specifications should be performed by trained service personnel.

Absolutely no physical, electrical or program modifications other than selection of standard options and accessories are to be made to this equipment.

Electrical connections other than those specified may not be performed, and physical alterations (holes, etc.) are not allowed.




Please call your local
FAIRBANKS SCALES REPRESENTATIVE
For any question, problems, or comments.

SECTION 2: USER OPERATIONS

2.1. Front Panel Key Functions

KEYS	FUNCTION
RED & GREEN LIGHT	<ul style="list-style-type: none"> Activates the Traffic Light function, if one is installed. When in the Programming Mode, pressing the RED button returns to the Weight Display, Except when modifying an entry.
TARE	Performs an AutoTare function.
IN & OUT BUTTONS	<ul style="list-style-type: none"> Manually selects the INBOUND or OUTBOUND mode. When programming, the OUT key sends a script to the printer.
UP & DOWN Arrows	Navigates through the menu selections.
MENU	<ul style="list-style-type: none"> The basic HOME button. Initiates the programming process into the different menus. Backs up one level on the Menu Tree. If the actions are not saved, pressing the MENU button voids this input.
NUMERIC Keys	<ul style="list-style-type: none"> Enters values for passwords, weight amounts, and configuration inputs. These keys can shortcut to desired entries in a selection item See 3.3. Short-cut Method for Menu Navigations.
ENTER	Activates and saves data input.
UNITS	<ul style="list-style-type: none"> Toggles and sets the unit types for the weight displayed. When programming, it inserts one line before the current one.
B/G/NET	<ul style="list-style-type: none"> Toggles active display between GROSS and TARE, in the GTN mode. Deletes one character in text/number.
ZERO	<ul style="list-style-type: none"> ZEROs the scale. When editing numbers or text, this clears the data.
PRINT	<ul style="list-style-type: none"> Initiates a PRINT cycle. Toggles between editing and showing the name of the current menu choice. Prints a sample ticket while in the Layout Menu.



2.2. Startup Procedure

1. Plug the unit in. The following sequence should occur:
 - a. **F36000** will scroll across the display, followed by the display driver and revision number.
 - b. **BOOT *** will appear
 - c. **LOAD *** will appear
 - d. **START *** will appear
 - e. The current weight on the scale will display.

2.3. Gross Weighing


The truck drives on the scale and the operator prints the result.

1. Press the **ZERO** key.
2. Drive the vehicle to be weighed on the platform.
3. Once the display stabilizes, press the **PRINT** key.
 - A **GTN** ticket prints with the **Gross Weight**.

2.4. Basic Weighing

BASIC MODE weighs the vehicle, then prints a ticket displaying the **Time, Date** and **Weight Amount** (either **Tare** or **Gross**). *This is its only function.*

- This mode **does not** have In/Out or Tare functions, (including storing Tares).
 - This mode requires specialized **keypad overlay stickers**.
1. With a **loaded vehicle** on the scale, press the **GROSS / PRINT** key
 - This is the **IN key**, before the template sticker was added.
 2. With an **empty vehicle** on the scale, press the **TARE / PRINT** key.
 - This is the **Out key**, before the template sticker was added.



2.5. Gross-Tare-Net Weighing


OPTION 1

- 1a. Press the **ZERO** key.
- b. Drive the empty vehicle to be weighed on the platform.
- c. Press the **TARE** button.
 - The weight is the captured **Tare Weight**.
- d. Exit the scale and load the vehicle with product.
- e. Drive back onto the scale.
- f. Once the display stabilizes, press the **PRINT** key and a Gross-Tare-Net Ticket will be printed.


OR

OPTION 2

- 1a. With the scale unloaded, press the **ZERO** key.
- b. Drive the loaded vehicle to be weighed on the platform.
- c. When the display stabilizes, press the **PRINT** key.
- d. When **KEY IN TARE AND PRESS ENTER** displays, enter a known **TARE amount** from an earlier weighment using the numeric keypad, then press **ENTER**.
 - A **GTN Ticket** will be printed.



NOTE: For printing only **Gross Weight**, enter **ZERO (0)** when prompted to enter a **Tare amount**.



2.6. Inbound/Outbound Weighing

Noted below are a few tips for the Inbound/Outbound Weighing Mode.

The **Loop ID** input varies depending on the installed software:

Revision 2.2.0 software and lower, Loop ID is **limited to 3 numeric characters**.

Revision 2.4.2 software and higher, **supports up to 15 alphanumeric characters**

The **Loop ID** is replaced by saving a new tare, or a saving a new keyboard tare ID.


There are 4 options when performing Inbound/Outbound Weighing.

Option 1

- 1a. Press the **ZERO** key.
- b. Drive the vehicle onto the platform, whether it is either full or empty.
- c. Once the display stabilizes, press the **IN** (Inbound) key.
- d. When the **Loop ID** legend text displays, enter the **Loop ID number** using the QWERTY keyboard or keypad, then press **ENTER**.
 - For complete information, see section, [Legends – Programmable](#).

Option 2

- 1a. Press **ENTER** to have the FB6001 auto-assign a **Loop ID number**.
- b. Drive off the scale and process the trailer, by either filling or emptying it.
- c. The same vehicle returns to the scale, either full or empty.
- d. Once the display stabilizes, press the **OUT** (Outbound) key.
- e. When the **Loop ID legend text** displays, enter the **LOOP ID Number** from an Inbound Transaction or saved TARE ID number, then press **ENTER**.





2.6. Inbound/Outbound Weighing, Continued

Option 3

- 1a. With the scale unloaded, press the **ZERO** key.
- b. Drive the loaded vehicle to be weighed on the platform.
- c. When the display stabilizes, press the **PRINT** key.
- d. When **KEY IN TARE AND PRESS ENTER** display, using the enter a known **TARE amount** from an earlier weighment, then press **ENTER**.
 - A **GTN Ticket** will print.

NOTE: For **Gross Weight** only to be printed, enter **ZERO (0)** when prompted to enter a *Tare amount*.

Option 4


- 1a. With the scale unloaded, press the **ZERO** key.
- b. Drive the loaded vehicle to be weighed on the platform.
- c. When the display stabilizes, press the **IN** or **OUT** key.
- d. When the **Loop ID legend text** displays, enter a **Tare ID number** from a stored **NEW TARE** or stored **NEW KEYBOARD TARE**, then press **ENTER**.
 - For complete information, see section, [**Legends – Programmable**](#).

The transaction is processed and an Outbound ticket prints

SECTION 3: PROGRAMMING OVERVIEW

3.1. Login

1. Press the **MENU** button to toggle between **Weight Display** and **Menu System**.




2. To enter the **MENU System**, when **LOGIN** displays, press the **ENTER** button.

- The display will be blank.

3. Input the **Service Password**, then press **ENTER**.

Supervisor Password = 1

OK displays first, then **AUDIT TRAIL** follows.



4. Press the **DOWN ARROW** to navigate through the following main menus.

Audit Trail
Operator Menu
Configuration Menu

5. Press **ENTER** to accept the option.

3.2. Defining the Programming Menus

The six (6) programming menus are briefly defined below.

AUDIT TRAIL	Identifies how many times and when changes have been made to the scale's Calibration or Configuration settings. NO Password required
OPERATOR MENU	Programs the Time/Date, Ticket Number, Load Cell Diagnostics, Tare Functions, Display Intensity and Keypad Sounds. NO Password required
CONFIGURATION MENU	Programs Customer Passwords, Communications Programming and Functions, Ticket Formats, Programmable Prompts and Legends, Device Input/Outputs, Weight Threshold, Report Configuration, Network Configuration, and Transaction Files Operations. Default Password = 1

3.3. Short-cut Method for Menu Navigations

Navigate through the different menu levels by entering a **Hot-key Number** and immediately access functions of the next higher level.

- The **Hot-key Number** displays in the flow charts to the **left** of the function.

Follow these steps to navigate using the HOT-KEY NUMBERS.

1. Press a **HOT-KEY NUMBER** to advance to the functions of the next menu level.
2. Continue pressing the next **HOT-KEY NUMBER**, moving forward in the menu tree, until the needed function is accessed.
3. Press **MENU** to move backward to the previous level.

SECTION 4: WEB INTERFACE

The configuration of all FB60XX series scales with **software version 2.0.1** or higher can now be performed through the instrument **OR** through the *Web Interface*.

NOTE: *At this time, scale calibration can **ONLY** be performed through the FB60XX instrument and **NOT** the **Web Interface**.*

The Web Interface can be accessed through most browsers (Internet Explorer, Firefox, Google Chrome) that is connected to a TCP/IP network **OR** by using an Ethernet crossover cable connected to a PC or tablet.

The first step in connecting remotely is to determine the connection address (IP address) of the instrument.

4.1. How to Connect Remotely to the FB60XX Series:

There are two (2) connection types used with the FB60XX.

DHCP (Dynamic Host Configuration Protocol) – Automatically addresses each node the first time it connects to the company's Intranet. A **DHCP** connection may change every few weeks so if you are not able to connect, re-verify the IP address on the instrument (see **To obtain the current IP address of the FB60XX**)

STATIC – Dedicated addresses assigned by the IT Department that are specific to each node, and do not change.

4.1.1. To obtain the current IP address of the FB60XX:

1. Login to the FB60XX
2. Scroll *down* to **CONFIGURATION**, press **ENTER**
3. Scroll *up* to **NETWORK**, press **ENTER**
4. Scroll *down* to **DHCP OPTIONS**, press **ENTER**
5. **MY IP** is displayed, press **ENTER**
6. The FB60XX IP address is displayed (**xxx .xxx .xxx .xxx**)

Write down the IP address

7. Press the RED Traffic light button twice to return to the weigh screen.

*Follow these steps to display, or to enter the **Static addresses** in the **NETWORK option**.*


4.2. Logging In to the Web Interface

1. Locate the **IP Address** of the FB60XX Series Instrument
(See also To obtain the current IP address of the FB60XX)

NOTE: In order to login to the Web Interface, you **MUST** logout of the FB60XX instrument. If you are **NOT** logged out, you will receive the message “**Front Panel in Use**” until you log out.

2. Input the correct **IP Address** of the FB60XX into the Address Bar of the web browser, then press **ENTER** on the remote computer.

3. Click on the **LOGIN** link.




4. Input the Default **Operator Password**, then press the **LOG IN** button.

Operator Password = 1.

The **Web Interface Home** screen appears.

After you are logged in successfully, the message “**Remote Config in Process**” will appear on the screen of the instrument.




4.3. Navigating the Web Interface

After successfully logging into the FB60XX Web Interface, the additional options of **Configuration Menu**, **Service Menu** and **Expansion Cards** will appear in the left-hand navigation. Additional options also will appear under **Operator Menu** and **Power Supply**.

NOTE: As stated previously, the Scale calibration can **NOT** be performed through the Web Interface but only through the instrument. All other settings are identical between the Web Interface and the instrument.

4.3.1. Audit Trail

The following options will appear in the Web Interface under **Audit Trail**:




Display: Displays all configuration changes made to each scale with drop-down menus for **Audit Report**, **number of items per page** and an available **Search**.

Print: Print the records from the Audit Report with options for number of items to print and a drop-down menu of available printers.

NJ Jumper State: Lets you know if this feature is active or inactive. See section [5.3. NJ Jumper](#) for more information about this option.

SW Revisions: Provides **Image**, **Model**, **Main**, **Drivers**, **Interpreter**, **Webconfig** information.

4.3.2. Operator Menu



New Tare: Add a new tare from the scale.

New Keyboard Tare: Manually enter a new tare.

Tare Delete: Provides the same options of **New Tare**, **New Keyboard Tare** and deleting a tare. A drop-down menu of all the existing tares and a **Search** is available.

Tare Report: Provides the same options as **Tare Delete** and a **Print** option with a drop-down list of available printers.

Time And Date: Provides the options of **Format Time and Date** and **Set Time and Date**.

Tickets: Set the starting value of tickets under **Number**, print the last created ticket under **Print Last Ticket** or add the ticket number of a ticket you wish to re-print under **Print Duplicate Ticket**.


Load Cell Diagnostics: Provides a live count of the **Cell Outputs** and **Errors**.

Utility: Provides drop-down menus for **Display Intensity**, **Keypad Beep**, scale **Volume** ranging from 10% (lowest volume) to 100% (highest volume) and **Mute**.

Options (Operator): When processing Inbound Loops, **Outbound Auto Suggest** displays the next available. When processing Inbound Loops, **Auto Instrument Inbound ID** automatically uses the next available (without displaying it). **Show Looping ID Text** displays *all* the stated information about the Loop, including the ID number, truck description, or any related text.

4.3.3. Configuration Menu

The following options will appear in the Web Interface under **Configuration Menu**:



Customer Password (Configuration Menu Password): Change the login password of the instrument. This is highly recommended.

Prompts: Messages to the Operator that ask a question, offer a choice, or relay an instruction. The **Name** field is a text entry field for naming a prompt. "Prompt 1" is the name used by the system to identify the prompt. **GTN**, **Inbound**, **Outbound**, **Basic In**, and **Basic Out** are all drop-down menu items that may be enabled or disabled.

Legends: The **Loop ID** field is a text entry field if you wish add a custom name.

Ticket Formats: The connected printer displays in the **Printer** field. The **Mode** drop-down menu lets tickets print in **GTN**, **Inbound**, **Outbound**, **BasicIn**, or **Basic Out** formats.

NOTE: If a printer does not display in the **Printer** field, no printer has been added to a COM port. See [8.2. COM Ports](#) to connect to an available printer.

Remote Display: Provides a drop-down menu to adjust **Display Mode** to continuous or print, **Type (Output)** to display by ticket number , Active Gross or Net Wt. **Enable 1605T** set to Yes or No.

Com Ports: Provides options for configuring the three input com ports and the single outgoing port. See section [8.2. COM Ports](#) for further details.

Threshold Weights: **Initial Weight** option provides up and down arrows to set the minimum amount the truck must weigh to initiate a weighment.

Traffic Light Control: **Control (Traffic Light)** either Automatic or Manual. The **Event to Signal** option lets the operator add a time to delay between 1-10 seconds to the signal. "Scale ID 1" is the name used by the system to identify the setting.

Reports: Provides options for displaying a report. **Type** provides an option for choosing Completed or Incomplete transactions. **Media** only shows "Jump Drive" in the drop-down menu. Reports must be generated to an inserted jump drive. **Sort By** provides the option of the report being sorted by Loop ID or Date/Time. **Delimiter** provides the option of generating a report in CSV or Tab format. See section [7.9. Reports](#) for more details.

Network: **DHCP Options** shows the network connectivity details of the instrument, **IP**, **Netmask**, **Gateway** and **DNS**. The **Network Output** provides an option for the **Type** output, of either Off or PC Continuous. The **Format** provides a choice of scale company output data. See also [Appendix 1 Data String Outputs](#) The **Local Port** provides up and down arrows to choose the correct port number on the outgoing PC.

- Network section under the **CONFIGURATION MENU** controls all network settings.
- Options include **DHCP** or **STATIC IP** (See **TIP2015-03**, for initial Network Setup)
- **DHCP OPTIONS** or* **STATIC IP** : Reports the IP address, Netmask, Gateway, Primary DNS

* Displayed value dependent on selected option of DHCP or STATIC.


Network Output: If configured, will send **NETWORK** continuous **SCALE** output.

Type is either OFF or PC Continuous.


Format: Select from 5 factory **DEFINED** formats:

Fairbanks, Toledo, Cardinal, Weigh-Tronix, Condec.

Local Port: default 5001, change only if requested by site.




Speed: This controls the speed and if full or half duplex is used on the network device. Default is AUTO and is usually enough+.



Transaction Files: This option allows for file deletion by five different options: **All Transactions**, **By Ticket Number**, **By Date Range**, **By Ticket Range** and **Incompletes**.

4.3.4. Scale Diagnostics



FB6001 Home Logout Help

MAIN MENU

Home

Logout

Help

AUDIT TRAIL

OPERATOR MENU

CONFIGURATION MENU

SCALE DIAGNOSTICS

Scale Diagnostics

Weights Cell Counts

Weights	Zero Counts	Cell	Scale	Cell	Zero Counts	Weights
			33280 lb	1	22229	33280 lb

Gross Weight: 33280 lb

Scale Diagnostics displays real-time data by **Weights** or **Cell Counts**. Click either Weights or Cell Counts to switch between options. The **Gross Weight** appears as well.

Weights: Displays **Weights** and **Zero Counts**.

Cell Counts: Displays **Current Counts** and **Zero Counts**.

SECTION 5: AUDIT TRAIL

The **AUDIT TRAIL** report displays all the configuration and calibration activities that were changed within the Instrument.


- Provided for Weights and Measures Officials.

5.1. Display

Filters the **Audit Trail Events** displayed, based on the selected option, after the **ENTER** button is pressed.

- This option is limited to **view only access**.

*The example below defines the **Audit Trail** report message.*



The screenshot shows a digital display with red text on a light blue background. The display is divided into two main sections. The top section contains two boxes: the left box displays 'MODE INBOUND / OUTBOUND' and the right box displays 'MODE - INSTRUMENT'. The bottom section contains a box displaying '28' followed by a box displaying '08/06/13 11 : 28'. Below the display, there is a text block explaining the information shown.

The unit is in the **INBOUND/OUTBOUND MODE** (Inbound/Outbound, GTN or Basic Mode).
The UNIT is currently in the **INSTRUMENT MODE** (Instrument, Scale or Complete).
There have been **28** “log-able” events performed on this instrument.
The **DATE** and **TIME** of the last recorded event (#28, in this case).

5.2. Print

Sets up the print output for the **Audit Report**, then prints all Configuration and Calibration activities that were changed within the Instrument.

- Offers a choice of the available printers configured to a COM Port.
- Prints some or all of the records.
- The **PRINT OUT** function activates the printer according to the settings.

*Follow these steps to print an **AUDIT TRAIL** report.*

1. Prepare the printer.
2. Open the **AUDIT TRAIL** menu, then select the correct printer.

TM-U295	TM-U230	SP-700	SP-2000
IDP-2550	TM-U590	SP-298	SP-2200
DemandPC	TM-U220		

NOTE: *The printer must be correctly configured before completing this option.*

3. Select the **NUMBER OR RECORDS** to include on the report.

Last (record)	10	50	All (records)
---------------	----	----	---------------

4. Select **PRINT OUT**, then press **ENTER**.

5.3. NJ Jumper State

This feature prevents unauthorized users from accessing certain programming menus.

1. In the **AUDIT TRAIL** menu, select the **NJ JUMPER STATE**.
2. Select either **NO JUMPER** or **JUMPER ON**.

5.4. SW Revision

This option displays all the current revision information, used for troubleshooting.

1. In the **AUDIT TRAIL** menu, select the **SW REVISION**.
2. Open any of the following options to view the revision number.

IMAGE – Displays the Software Image revision number and software part number.

MODEL – Displays which model is selected during the last software installation.

- Either **FB6001** or **FB6001**.

MAIN – Displays the current revision level of the Main Software Program..

DRIVERS – Displays the current revision level of the software driver program.

INTERPRETER – Displays the current revision level of the software interpreter.

WEBCONFIG – Displays the current revision level of the **Web Configuration** software.


SECTION 6: OPERATOR MENU

6.1. New Tare

Follow these steps to store a **New Tare**, using the weight on the scale platform, then recalled later as a saved **Tare Weight**.

1. In the **Operator Menu**, press the **DOWN arrow** until **NEW TARE** displays, then press **ENTER**.
2. When **ID (TARE)** displays, Press **ENTER**.
3. When the last stored Tare ID number displays, input the new tare number, then press **ENTER**.
4. When **WEIGHT (TARE)** displays, press **ENTER**.
5. The current weight on the platform is displayed with annunciator on front panel lit to identify active units; press **ENTER** to capture the weight.
 - If there is motion on the platform at that time; **MOTION _ PLEASE WAIT** displays until the scale settles, and then the weight can be captured.
6. When **VEHICLE DESCRIPTION** displays, press **ENTER**.
7. When the current **Vehicle Description** displays. input the new **Vehicle Description**, then press **ENTER**.
 - This can be the truck drivers' plate number, the vendor ID, or another designated identifying number.

$$\text{GROSS WEIGHT} - \text{TARE WEIGHT} = \text{NET WEIGHT}$$



6.1. New Tare, Continued

8. When **SAVE** displays, press **ENTER**.
9. Using the **DOWN ARROW**, select either **YES** or **NO**, then press **ENTER**.
 - **YES** saves the captured TARE Weight Value, ID, and Vehicle Description.
 - **NO** does not save the Tare Data.

NOTE: If the Tare ID entered in Step 3 is a duplicate of an existing Stored Tare, then **OVERWRITE? - NO** will display.

10. To abort saving the tare, press **ENTER**.
11. To overwrite the existing tare data with the new tare data, press the **DOWN arrow** until **OVERWRITE? - YES** displays, then press **ENTER** **NEW TARE** displays.

6.2. New Keyboard Tare

Follow these steps to store a **New Tare**, using the keyboard, to be recalled later as a saved tare weight.

1. In the **Operator Menu**, press the **DOWN arrow** until **NEW KEYBOARD TARE** displays, then press **ENTER**.
2. When **ID (TARE)** displays, press **ENTER**.
2. The last stored Tare ID number is displayed, input the new tare number, then press **ENTER**.
3. When **WEIGHT (TARE)** displays, press **ENTER**.
4. The last tare entry weight is displayed; enter a new tare value via the keyboard, then press **ENTER**.
5. When **UNITS** displays, press **ENTER**.
6. When the current **Units** setting displays, use the **UP/DOWN arrows** to select the correct one, then press **ENTER**.
 - lb, kg, ton, or tonne.
7. When **VEHICLE DESCRIPTION** displays, press **ENTER**.
8. When the current **Vehicle Description** displays; input the new **Vehicle Description**, then press **ENTER**.
 - This can be the truck drivers' plate number, the vendor ID, or another designated identifying number.
9. When **SAVE** displays, press **ENTER**.

10. Using the **DOWN** arrow, select either **YES** or **NO**, then press **ENTER**.

- Selecting **YES** saves the **Tare**.
- Selecting **NO** does not save the **Tare**.

NOTE: If the **Tare ID** entered in **Step 3** is a duplicate of an existing **Stored Tare**, then **OVERWRITE? - NO** will display.

11. To abort saving the tare, press **ENTER**.

12. To overwrite the existing tare, press the **DOWN ARROW** until **OVERWRITE?** displays, then press **ENTER** when **YES** displays.

NEW TARE displays.

6.3. Tare Delete

This option displays a list of all the stored **New Tare** and **New Keyboard Tare** entries.

Follow these steps to delete a stored Tare.

1. While in the **OPERATOR MENU**, press the **DOWN** arrow and select the **TARE DELETE**, then press **ENTER**.
2. Press the **DOWN/UP** arrows to scroll through the stored tares.
2. To delete a tare, press the **ZERO** key.

6.4. Tare Report

This option displays the stored New Tares and New Keyboard Tares, then prints a Report as selected by the operator.

Follow these steps to set the Tare Report.

1. While in the **OPERATOR MENU**, press the **DOWN** arrow and select the **TARE REPORT**, then press **ENTER**.
- 2a. When **DISPLAY** appears, press **ENTER**.
 - This shows the Stored Tares, listing the Tare ID Number, Weight, Date, and the Tare Description.
- b. Use the **UP/DOWN** arrows to scroll through the list.
- c. Press **MENU** to return to the **Tare Menu**.

OR...

- 2a. Use the **DOWN** arrows to select **PRINT**, then press **ENTER**.
- b. Press **ENTER** when **PRINTER** displays.

- c. Select an available **PRINTER**.
- d. Press **ENTER** when **PRINT OUT** displays for the **Tare Report**.
- e. Press **MENU** when **PRINTING COMPLETE --- MENU TO CONTINUE** displays.

6.5. Time & Date

6.5.1. Format Time & Date

Use the **UP/DOWN Arrows**, **Numeric keys**, **MENU** and **ENTER** buttons to format the Time and Date.

1. While in the **OPERATOR MENU**, select the **TIME AND DATE** option, then press **ENTER**.
2. When **FORMAT TIME AND DATE** display, use the **UP/Down Arrow keys** to select one of the following options, then press **ENTER**.

H-M	H-M-S
HH-MM	HH-MM-SS

3. When **AM/PM** display, press **ENTER**.
4. Using the **DOWN arrow**, select **12 HOUR** or **24 HOUR** format, then press **ENTER**.
5. When **DATE FORMAT** displays, Press **ENTER**.

Options are:

MDYY	
MDYY	(this is for a 4 digit year date)
DDMMYY	
DDMMYY	(this is for a 4 digit year date)
YYMMDD	
YYMMDD	(this is for a 4 digit year date)
MMDDYY	
MMDDYY	(this is for a 4 digit year date)
DDMMYY	
DDMMYY	(this is for a 4 digit year date)
YYMMDD	
YYMMDD	(this is for a 4 digit year date)

6. Using the **UP/DOWN arrows**, select the best format for the customer's needs, then press **ENTER**.

7. When **DATE SEPERATOR** displays, press **ENTER**.

Options are:

/

--

(SPACE)

8. After the selection is made, the display returns to **FORMAT TIME AND DATE**.

6.5.2. Set Time & Date

Use the **Arrow, Numeric and ENTER Keys** to set the time and date.

With the FB6000 displaying **FORMAT TIME AND DATE** use the **DOWN arrow** to display **SET TIME AND DATE** option, then press **ENTER**.

YEAR will display. Press **ENTER**, key in the year, then press **ENTER**.

MONTH will display. Press **ENTER**, key in the month, then press **ENTER**.

DAY will display. Press **ENTER**, key in the day, then press **ENTER**.

HOURL will display. Press **ENTER**, key in the hour, then press **ENTER**.

MINUTE will display. Press **ENTER**, key in the minute, then press **ENTER**.

SAVE TIME AND DATE will display. Press **ENTER** to save the new Time & Date.

TIME SET - PRESS KEY TO CONTINUE will display.

The Time & Date currently configured in the FB6000 will now scroll across the display. Press **ENTER**.

Display will now show **SET TIME AND DATE**.

NOTE: Time must always be entered in military (24 hour) format, i.e. 8 am is entered as 08. 2 pm entered as 14.

6.6. Tickets

Follow these steps to access a specific ticket by entering the **Ticket Number**.

1. While in the **OPERATOR MENU**, select the **TICKET NUMBER** option, then press **ENTER**.

Step 2 (option 1)

- 2a. When **NUMBER** displays press **ENTER**.
- b. Using the numeric keypad, in the **Ticket Number**, press **ENTER**.
 - Allows a maximum entry of **six (6) digits**.
 - This sets the value for the **Ticket Number** to be used in the next printing transaction.
- c. Press the **DOWN arrow** until the **LAST TICKET - PRINT** option displays, then press **ENTER**.
 - This prints a duplicate of the last ticket transaction.

Step 2 (option 2)

- 2a. Press the **DOWN arrow** until the **DUPLICATE -- PRINT** option displays, then press **ENTER**.
- b. When **ENTER TICKET NUMBER** appears, enter the desired ticket number, then press **ENTER**.
 - This option prints a duplicate ticket for the number as input by the operator.)

6.7. Load Cell Diagnostics

Load Cell Diagnostics gives a quick snapshot of how each load cell is performing, used for easier troubleshooting capabilities.

1. While in the **OPERATOR MENU**, select the **LOAD CELL DIAGNOSTICS** option, then press **ENTER**.
2. When **ID** displays, press **ENTER**.
3. When **CELL OUTPUTS** displays, press **ENTER**.

Step 4 (option 1)

- 4a. When **DISPLAY** appears, press **ENTER**.
- b. When **COUNTS** displays, press **ENTER**.
- c. Using the **DOWN/UP arrows**, select the desired load cell (**CELL1** thru **CELL 16**), then press **ENTER**.
 - The counts for the selected load cell will be displayed.
- d. Press **ENTER** to return to **Cell Selection**.
- e. Press **MENU** to return to **DISPLAY MENU**.



- f. Press **DOWN** arrow until **ERRORS** displays, then press **ENTER**.
 - If **NONE** appears, then there are no errors to display.
- e. If errors do occur, use the **DOWN** arrow to select one of the listed Cell numbers that have recorded an error, then press **ENTER**.
 - The **ERROR TYPE**, **DATE**, and **GHOST STATUS** for the recorded error will be displayed.
 - Press **ENTER** three times to return to **Cell Outputs Menu**.

Step 4 (option 2)

- 4a. Press the **DOWN** arrow until **PRINT** displays, then press **ENTER**.
- b. When **PRINTER** displays, press **ENTER**.
- c. Press the **DOWN** arrow to select a printer if multiple printers are configured, then press **ENTER**.
- d. When **COUNTS** displays, press **ENTER** to print the **Cell Counts**.

*The following categories are noted on the **COUNTS** print-out.*

CELL NUM – Identifies the load cell in the scale platform.

CAL COUNTS – the zero load cell count stored at calibration.

CURRENT – the current load cell counts.

WEIGHT – the current weight value.

6.8. Utility

6.8.1. Set Display Intensity

1. While in the **OPERATOR MENU**, press the **DOWN** arrow and select the **UTILITY** option, then press **ENTER**.
2. Press **ENTER** when **SET DISPLAY INTENSITY** appears.
3. Select **LOW**, **MEDIUM** or **HIGH**, then press **ENTER**.

6.8.2. Key Pad Beep, Set Volume, Mute

KEY PAD BEEP

1. In the **UTILITY MENU**, press the **DOWN** arrow and select the **KEY PAD BEEP** option, then press **ENTER**.

2. Select **ON** or **OFF**, then press **ENTER**.

SET VOLUME

3. In the **UTILITY MENU**, press the **DOWN arrow** and select the **SET VOLUME** option, then press **ENTER**.
4. Adjust the **BEEP volume** to the desired level.

MUTE

5. In the **UTILITY MENU**, press the **DOWN arrow** and select the **MUTE** option, then press **ENTER**.
 - This silences the **Key Pad Beep** until it is reversed.

6.9. Options (Operator)

1. While in the **OPERATOR MENU**, press the **DOWN arrow** and select **OPTIONS (OPERATOR)**, then press **ENTER**.
2. Press the **DOWN arrow** and press **ENTER** to select one of these options.

OUTBOUND AUTO SUGGEST – When processing Inbound Loops, this selection displays the next available one.

AUTO INCREMENT INBOUND ID – If enabled, the instrument will suggest a Loop ID one value higher than the last Inbound ID used. Otherwise, it will use the lowest available ID.

SHOW LOOPING ID TEXT – This selection displays *all* the stated information about the Loop, including the ID number, truck description, or any related text.

SECTION 7: CONFIGURATION MENU

7.1. Change Customer PW

1. In the Configuration Menu, press **ENTER**.
2. When **CHANGE CUSTOMER PASSWORD** displays, press **ENTER**.
3. When **ENTER PASSWORD** displays, **ENTER**.
4. Present **Customer Password** displays.
5. Input the new **Customer Password**, then press **ENTER**.
6. When **CONFIRM PW** displays, press **ENTER** again.
 - If the password is entered incorrectly, **ERROR** displays, then the instrument returns to the previous step.

7.2. Prompts – Programmable

PROMPTS are messages to the Operator that ask a question, offer a choice, or relay an instruction.

1. In the Configuration Menu, press the DOWN arrow until **PROMPTS PROGRAMMABLE** displays.
2. Press **ENTER** when **PROMPT 1** displays.
3. When **NAME** displays, press **ENTER** to prompt the required text.
4. Enter the desired **Entry Prompt 1** text heading.
 - The operator can enter alphanumeric text by either using the **UP** and **DOWN** arrows of the **keypad**, or using the **external keyboard**.
 - When **ENABLED**, this feature displays a **Programmable Prompt** text box.
 - Some examples for this field include “**Truck type**”, “**Driver’s last name**”, “**Special Notes**”, etc.
5. Press **ENTER** to save the **Prompt 1** text, which then can be printed on the ticket.
 - This print command is activated with **<write (Prompt 1 Text)>**.

7.2. Prompts – Programmable, Continued

6. Press the DOWN arrow and choose **GTN, INBOUND, OUTBOUND, BASICIN** or **BASICOUT**, then press **ENTER**.
7. Press the **DOWN arrow** to select either **DISABLED** or **ENABLED**, then press **ENTER** to confirm this selection.
 - Selecting **ENABLED** initiates the prompt during the weighment transaction when that operating mode is used.

7.3. Legends – Programmable

*Activating this option displays a **LOOP ID** for the operator to enter.*

1. In the Configuration Menu, press the **DOWN arrow** until **LEGENDS - PROGRAMMABLE** displays.
2. Press **ENTER** when **LOOP ID** displays to edit this **LEGENDS** text.
3. Enter the desired **LOOP ID text**, then press **ENTER** to save it.
 - The Operator can enter alphanumeric text using the up/down arrows on the keypad, or using an external Keyboard..
 - This print command is activated with **<write (Loop ID Text)>**.

7.4. Ticket Formats

For complete descriptions and procedures, see [SECTION 9: FORMATTING TICKETS](#).

IMPORTANT NOTE: *Always configure the **COM Ports** first before formatting tickets*

7.5. COM Ports

For complete descriptions and procedures, see [8.2. COM PORTS](#).

7.6. Threshold Weights

THRESHOLD WEIGHT sets the minimum amount the truck must weigh to initiate a weighment.

- This feature is not used when the **Traffic Light Control** is set to **MANUAL**.

Valid values = 0 to 99,999

Default setting = 1000

*Follow these steps to set the **THRESHOLD WEIGHT**.*

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **THRESHOLD WEIGHTS** displays.
2. Press **ENTER**.
3. When **INITIAL WEIGHT** displays, press **ENTER**.
4. Enter the desired **Threshold Weights** value, then press **ENTER**.
5. When **MAXIMUM WEIGHT** displays, press **ENTER**.
6. When **THRESHOLD** displays, press **ENTER**.
7. Enter the desired Maximum Threshold Weight value, then press **ENTER**.
8. **ALLOW OVERWEIGHT TRANSACTION** displays, press **ENTER**.

NO = The FB6000 will NOT allow the transaction to continue.

The FB6000 will display **WEIGHT EXCEEDS MAX THRESHOLD -- UNABLE TO CONTINUE**.

NOTE – THERE IS NO MEANS TO OVERRIDE THIS SETTING AT THE WEIGH SCREEN. The load on the overweight vehicle must be adjusted before a weighment can be completed.

YES = The FB6000 will prompt the Operator with options.

7.7. Traffic Light Control

NOTE: See [SECTION 8.4. TRAFFIC LIGHT CONTROL](#) for complete instructions on programming the traffic light.

7.8. Reports

Follow these steps to setup and generate the **TRANSACTION REPORTS**.

1. In the **CONFIGURATION MENU**, press the **DOWN arrow** until **REPORTS** displays, then press **ENTER**.
2. When **TYPE** displays, press **ENTER**.
3. Using the **DOWN arrow**, select either **COMPLETED TRANSACTIONS** or **INCOMPLETE TRANSACTIONS**, then press **ENTER**.
4. When **MEDIA TYPE** displays, press **ENTER**.
5. When **JUMP DRIVE** displays, press **ENTER**.
 - A **Jump Drive** must be inserted into a **USB port** for a report to be generated.
 - The **Jump Drive** must then be inserted into a printer or PC to print the document or process it further.
6. When **SORT BY** displays, use the **UP/DOWN arrows** to select the **LOOP ID**, **DATE/TIME** or the **TICKET#** for the desired method of sorting the data, then press **ENTER**.
7. When **DELIMITER** displays, using the **DOWN arrow**, select one of these options, then press **ENTER**.
 - **CSV** (**C**omma **S**eparated **V**alue) – Commas separate data items in the Transaction Report.
 - **TAB** – Tabs are used to separate data items in the Transaction Report.
8. When **GENERATE** displays, press **ENTER** to store the **Report** to the **Jump Drive**.
 - **SUCCESS TYPE_YYYY-MM-DDTHM.XSV SAVED - MENU TO EXIT** displays with the data file name information when the report is stored.
 - Where **TYPE** is either Completed or Incomplete.
 - **YYYY** is the **year**; **M** is the **month**; **H** is the **hour**; **M** is the **minute**; and **X** is either **C** for **CSV** or **T** for **TAB**.
 - **NO USB DRIVE FOUND - MENU TO EXIT** will display if the USB drive is not installed.
9. Press **MENU** to exit.

7.9. Network IP Settings

The **NETWORK option** displays and provides access to configures the ethernet TCP/IP network connection addresses.

There are two (2) connection options available with the FB6000.

DHCP (Dynamic Host Configuration Protocol) – The customers DHCP network automatically assigns the IP address for the FB6000 attached to the network. When using DHCP, the IP address of the FB6000 can change each time the customers network reissues the leases for the IP addresses on the network. This is why this type of network is known as **Dynamic**.

STATIC – Dedicated, specific IP address. This IP address will be provided by the customers IT Department. To use a Static IP address the customers IT staff must provide you the following information:

- IP address
- Netmask
- Gateway
- Primary DNS

To enter a **Static address**:

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **NETWORK** displays, then press **ENTER**.
2. When **USE DHCP?** displays, press **ENTER**.
3. When **DHCP** displays, press the **DOWN** arrow until **STATIC** displays, press **ENTER**.
4. **USE DHCP?** will display again. Press the **DOWN** arrow until **STATIC IP** displays. Press **ENTER**.
5. **IP ADDRESS** displays. Key in the IP Address and press **ENTER**.
6. **NETMASK** displays. Key in the Netmask and press **ENTER**.
7. **GATEWAY** displays. Key in the Gateway and press **ENTER**.
8. **PRIMARY DNS** displays. Key in the DNS and press **ENTER**.
9. Press the **DOWN** arrow until **APPLY CHANGES** displays. Press **ENTER**.
10. **NO** displays. Press the **DOWN** arrow until **YES** displays. Press **ENTER**.

NOTE – If you do not APPLY after entering the settings described above, the settings will **NOT** be saved.

NOTE – The instrument **MUST** be connected to a network or you will get an **INTERN** error when you apply changes.

- Press the RED traffic light button to return to the weight screen.
- ** Static IP settings are now complete.**

To configure the FB6000 for a **DHCP address**:

1. In the CONFIGURATION MENU, press the DOWN arrow until **NETWORK** displays, then press **ENTER**.
2. When **USE DHCP?** displays, press **ENTER**.
3. Either **DHCP** or **STATIC** will display, press the **DOWN arrow** until **DHCP** displays, press **ENTER**.
4. **USE DHCP?** will display again. Press the RED traffic light button to return to the weight screen.

Reboot the FB6000.

**** DHCP settings are now complete. ****

7.10.Transaction Files

Follow these steps to delete **TRANSACTION FILES**.

1. In the **CONFIGURATION MENU**, press the DOWN arrow until **TRANSACTION FILES** displays, then press **ENTER**.
2. Press the DOWN arrow to select one of the following options, then press **ENTER**.
 - **DELETE ALL TRANSACTIONS** removes all transactions.
 - **DELETE BY TICKET** removes one specific transaction based on the ticket number entered.
 - **DELETE BY DATE RANGE** removes all transactions within the entered date range.
 - **DELETE BY TICKET RANGE** removes all transactions within the entered ticket range.
 - **DELETE INCOMPLETES** removes all the Inbound transactions.
 - **DELETE INCOMPLETES BY LOOP ID** delete incomplete transactions by selecting their Loop ID.

C A U T I O N

Performing any of these **TRANSACTION FILES** functions will erase some or all the current transaction data records.

C A U T I O N

Performing any of these **TRANSACTION FILES** functions will erase some or all of the current transaction data records.

SECTION 8: SERIAL INPUT / OUTPUT

8.1. Printers

8.1.1. Printer Switch Settings

ROLL TAPE PRINTER	SW 1 ON	SW 2 ON	SW 3 ON	SWITCH SETTINGS
iDP3550 (28810)	2, 3, 4, 8	1, 2, 3, 5, 6	—	9600 Baud, No Parity, 8 Data and 1 Stop Bit.

TICKET PRINTER	SW 1 ON	SW 2 ON	SW 3 ON	SWITCH SETTINGS
TM-U590 (24740)	1, 3, 7	All OFF	—	9600 Baud, No Parity, 8 Data and 1 Stop Bit.
TM-U295 (24741)	1, 3	All OFF	—	9600 Baud, No Parity, 8 Data and 1 Stop Bit.
SP298	All OFF	3	1, 5	9600 Baud, No Parity, 8 Data and 1 Stop Bit.
SP700	1 thru 7	1 thru 6	1, 5	9600 Baud, No Parity, 8 Data and 1 Stop Bit.
SP2000	All OFF	3	1, 5	2400 Baud, Even Parity, 7 Data and 2 Stop Bit.
SP2200	2, 3, 8	All OFF	All OFF	2400 Baud, No Parity, 7 Data and 2 Stop Bit.
TM-U230 (30954)	All OFF	2, 5, 8	—	9600 Baud, No Parity, 8 Data and 1 Stop Bit.

No switch bank present inside the printer.

NOTE: The Fairbanks Scales standard default COM Port settings for all the printers is **9600 Baud, No Parity, 8 Bits, and 1 Stop Bit.**

8.1.2. Printer Cabling

The chart below shows the connections for the two cable types used with the printers.

14807 CABLE KIT


WIRE	DB-9 INSTRUMENT	COLOR	DB-25 PRINTER	DESC.
1	P1-2	R	P2-2	RX
2	P1-3	W	P2-3	TX
3	P1-5	G	P2-7	GROUND
4	P1-7	O	P2-8	JUMPERED

14809 CABLE KIT

Used only with the 3550 Printer.

WIRE	DB-9 INSTRUMENT	COLOR	DB-25 PRINTER	DESC.
1	P1-3	R	P2-3	TX to PRINTER
2	P1-8	W	P2-20	BUSY
3	P1-5	G	P2-7	GROUND

8.1.3. iDP3550 Tape Printer Settings



DS2	ON	OFF
1	X	
2	X	
3	X	
4		X
5	X	
6	X	
7		X
8		X

DS1	ON	OFF
1		X
2	X	
3	X	
4	X	
5		X
6		X
7		X
8	X	
9		X
10		X

BAUD	9600
PARITY	No
DATA BITS	8
STOP BIT	1

8.1.4. TM-U590 Ticket Printer Settings


- For FB6001/2/3 Instrument Desktop and NEMA 4X SERIAL communications, use cable **14807**.

BAUD	9600
PARITY	No
DATA BITS	8
STOP BIT	1

Set the printer **dip switches** as listed below.

DSW 1: 1, 3, and 7 = **ON** only.

DSW 2: All Switches = **OFF**




8.1.5. TM-U295 Ticket Printer Settings

- For FB6001/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.

Set the printer **dip switches** as listed below.

SW1: 1 and 3 = **ON**

Remainder = **OFF**




BAUD	9600
PARITY	No
DATA BITS	8
STOP BIT	1

8.1.6. TM-U220 Tape Printer

- Uses **SERIAL** communication.
- Use cable **25932**.

BAUD	9600
PARITY	No
DATA BITS	8
STOP BIT	1



WIRING

Cable **25932** Wiring for COM 1-3

DB-9 INSTRUMENT	DESCRIPTION	WIRE COLOR	DB-25 PRINTER	DESCRIPTION
2	RxD	BR	2	TxD
3	TxD	R	3	RxD
4	DRT	O	6	DSR
5	SG	Y	7	SG
6	DSR	G	20	DTR
7	RTS	BL	5	CTS
8	CTS	BK	4	RTS

Cable **25932** Wiring for Serial Expansion Module*

RS232 PORT 1: COM7 XX	DESCRIPTION	WIRE COLOR	DB-25 PRINTER	DESCRIPTION
TB1a-2	RxD	BR	2	TxD
TB1a-3	TxD	R	3	RxD
TB1a-4	DRT	O	6	DSR
TB1a-5	SG	Y	7	SG
TB1b-6	DSR	G	20	DTR
TB1b-7	RTS	BL	5	CTS
TB1b-8	CTS	BK	4	RTS

* Must remove the 9-pin connector.

8.1.6. TM-U220 Tape Printer, Continued

DIP SWITCH 1 (Serial Interface)

SWITCH	FUNCTION	ON	OFF
1	Data receive error	Ignored	Prints “?”
2	Receive buffer capacity	40 bytes	4KB
3	Handshaking	XON/XOFF	DTR/DSR
4	Work length	7 bits	8 bits
5	Parity check	Yes	No
6	Parity selection	Even	Odd
7	Transmission speed	4800 bps	9600 bps
8	BUSY condition	Receive buffer full	Receive buffer full or Offline

Default settings are in bold.


DIP SWITCH 2 (Serial Interface)

SWITCH	FUNCTION	ON	OFF
1	Print Column	42/35	40/33
* 2	For internal use only (auto-cutter) (do not change)	Enabled	Disabled
3	Pin 6 reset signal	Used	Not used
4	Pin 25 reset signal	Used	Not used
5	Undefined	--	--
6	Internal use only (flash memory rewriting) (Do not change)	Enabled	Disabled
7	Undefined	--	--
8	Serial Interface section	Memory Switch	Dip Switch

Default settings are in bold.

* The TM-U220 Tape Printer DAT (dk gray case, w/cutter) will have DSW2 switch #2 set to ON. TM-U220 Tape Printer (white case, no cutter) will have DSW2 switch #2 set to OFF. All other switch settings are identical between printers.

Access the **Dip Switches** by unfastening the screw and removing the cover plate, found on the bottom of the printer.





8.1.7. SP298 Printer Settings

- For FB6001/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.

BAUD	9600
PARITY	No
DATA BITS	8
STOP BIT	1

ACCESSING THE DIP SWITCHES

- Remove all power from the printer, as well as all Network cables from between the printer and the Instrument.
- Remove the **Printer Cover**.
- Press down with a screwdriver at **Location “A”** marked in the illustration below, and carefully slide the **Document Table** in the direction indicated by the arrow until it is out of the way.
 - It is not necessary to remove the document table completely. Just move it enough to access the DIP Switches inside.
- Set the **DIP Switches** into their correct positions.
- Slide the Document Table back into place while pressing down at **Location “A”**.
- Replace the **Print Cover**.



8.1.7. SP298 Printer Settings, Continued

DIP Switch Settings (SERIAL INTERFACE)

SWITCH	FUNCTION	ON	OFF
1	Baud Rate	See table below.	
2			
3	Data Length	8 bits	7 bits
4	Parity Check	Disabled	Enabled
5	Parity	Odd	Even
6	Handshake	DTR/DSR	XON/XOFF
7	Command Emulation	See table below	
8			
9	Pin #6 (DSR) reset signal	Enabled	Disabled
10	Pin #25 (INIT) reset signal	Enabled	Disabled

Baud Rate Settings Table

BAUD RATE	SWITCH 1	SWITCH 2-2
4800 bps	OFF	ON
9600 bps	ON	ON
1920 bps	ON	OFF
3840 bps	OFF	OFF

Command Emulation Table

COMMAND EMULATION	SWITCH 7	SWITCH 8
Star Mode	ON	ON
ESC/POS (TM-295)	ON	OFF
ESC/POS (TM-290)	OFF	OFF
Not used (*)	OFF	ON

* Never set **Switch 7** to **OFF** at the same time that **Switch 8** is set to **ON**.



8.1.8. SP700 Printer Settings

For FB6001/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.

BAUD	9600
PARITY	No
DATA BITS	8
STOP BIT	1

There are **two (2) dip switch** locations on the Star SP700 Printer.

- Underneath the printer, behind a protective cover is **DIP Switch 1**.
- **DIP Switch 2** is on the Serial Interface Board.



SWITCH	FUNCTION	ON	OFF
1-1	Always ON	Should be set ON	
1-2	Auto Cutter *	Invalid	Valid
1-3	Always ON	Should be set ON	
1-4	Command Emulation	Star	ESC/POS
1-5	USB mode **	Printer Class	Vendor Class
1-6	2 Colors Printing	Valid	Invalid
1-7	Reserved		
1-8	Print head model ***	18-pin wire	9-pin wire

* The factory settings for enabling/disabling the Auto Cutter are as listed below.

- Models without Auto Cutter: Invalid (**Switch 1-2 = ON**).
- Models with Auto Cutter: Valid (**Switch 1-2 = OFF**).

NOTE: Only program the **Auto Cutter** function with models that have the **Auto Cutter Accessory** installed.

- This is models with a tear bar.
- A mechanical error will occur.

** **USB Interface** model only.

*** Do not change the default setting (**Switch 1-8 = OFF**).

12.1.8. SP700 Printer Settings, Continued

DIP Switch 2

SWITCH	FUNCTION	ON	OFF
2-1	Baud Rate	See table below.	
2-2			
2-3	Data Length	8 bits	7 bits
2-4	Parity Check	Disabled	Enabled
2-5	Parity	Odd	Even
2-6	Handshake	DTR/DSR	XON/XOFF
2-7	Pin #6 (DSR) reset signal	Valid	Invalid
2-8	Pin #25 (INIT) reset signal	Valid	Invalid

Baud Rate Settings Table

BAUD RATE	SWITCH 2-1	SWITCH 2-2
4800 bps	OFF	ON
9600 bps	ON	ON
1920 bps	ON	OFF
3840 bps	OFF	OFF

8.1.9. SP2000 Printer Settings


The SP2000 is a Dot Matrix ticket printer. The following switch settings and cable requirements will work with the default format.

- For FB6001/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.

BAUD	2400
PARITY	EVEN
DATA BITS	7
STOP BIT	2

Set the printer's **dip switches** according to the following:

- **DSW 1:** All **OFF**.
- **DSW 2:** **Three (3) ON** only.
- **DSW 3:** **One (1) and five (5) ON** only.



8.1.10. SP2200 Printer Settings

The SP2200 is a Dot Matrix ticket printer. The following switch settings and cable requirements will work with the default format.

- FB6001/2/3 Desktop and NEMA 4X use cable **14807**.


BAUD	2400
PARITY	NO
DATA BITS	7
STOP BIT	2

Set the printer's **dip switches** according to the following:

- **DSW 1:** Two (2), three (3), and eight (8) **ON** only.
- **DSW 2** and **3:** All **OFF**.

8.1.11. TM-U230 Printer Settings

- For FB6001/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.



BAUD	9600
PARITY	No
DATA BITS	8
STOP BIT	1

DIP Switch 1 Settings (SERIAL INTERFACE)

SWITCH	FUNCTION	ON	OFF
1	Data receive error	Ignored	Prints “?”
2	Receive buffer capacity	1KB	16KB
3	Handshaking	XON/XOFF	DTR/DSR
4	Work length	7 bits	8 bits
5	Parity check	Yes	No
6	Parity selection	Even	Odd
7	Transmission speed	4800 bps	9600 bps
8	BUSY condition	Receive buffer full	Receive buffer full or Offline

DIP Switch 2 Settings (SERIAL INTERFACE)

SWITCH	FUNCTION	ON	OFF
1	Sections number of characters per line (cpl) 7 x 9 font/ 9 x 9 font	42/35	40/33
2	For internal use only (Auto-cutter) (do not change)	Enabled	Disabled
3	Pin 6 reset signal	Used	Not used
4	Pin 25 reset signal	Used	Not used
5	PAPER OUT LED flashing pattern	Flashes	Lights on
6	For internal use only (flash memory rewriting) (Do not change)	Enabled	Disabled
7	For internal use only (Internal synchronization) (Do not change)	Asynchronous	Synchronous with clock
8	Internal buzzer	Disabled	Enabled

8.2. COM Ports

The FB6001/2/3 Instrument has numerous ports and outlets allowing different Input/Output devices to be utilized.

The back of the Instrument has a 120V outlet, but the unit also supports 220V Scale Input.

The FB6001/2/3 instrument has three (3) standard **Serial Output COM Ports**.

- These are configured for **RS-232** communications.
- Serial Outputs can be customized to provide specific configured data string protocols, configuration parameters, using output modes such as **PC Polled, PC Continuous, Demand PC, Off, Remote Display**, and then **all printers** listed in **Section 9**.


The **Console Port** is a RS232 Connection.

- Currently unused.

There are three (3) **USB Ports** used for different external components, such as a keyboard, USB Flash Drive, etc.

The three (3) **ACC holes** are used when wiring external component accessories, such as a remote display, traffic lights, etc.

The ethernet port is used for the **WEB FORMATTING**.



8.2.1. Programming COM PORTS

NOTE: Always configure the Printer before formatting the tickets.

Follow these steps to program the **FOUR (4) COM PORTS**.

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **COM PORTS** displays.
2. Press **ENTER**.
3. Using the **DOWN** arrow, select the desired **COM PORT** to configure, then press **ENTER**.
 - **COM Ports** one thru three (1-3) are standard **Serial ports**.
 - COM Port four (4) is dedicated to **20 mA Output**, currently used only for the Remote Display.

8.2.2. Configuring the Remote Display Output

Follow these steps to program the **REMOTE DISPLAY**

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **COM PORTS** displays.
2. Press **ENTER**.
3. Using the **DOWN** arrow, select the desired **COM 4 & 20 MA**, then press **ENTER**.
 - **DEVICE ATTACHED** is displayed. Press **ENTER**
 - Use the **UP/DOWN** arrows to display **REMOTE DISPLAY**, then press enter.
 - **LOAD DEFAULT SETTINGS?** is displayed, press **ENTER**.
 - Use the **UP/DOWN** arrow to display yes, then press **ENTER**.
 - This will load the default settings for Fairbanks 160x remote displays.
 - **SETTINGS** is displayed. If using a non-Fairbanks remote display or if the settings otherwise require changes, press **ENTER** to enter the setting menu.
 - The available settings include: Baud rate, parity, stop bits data bits, and checksum.

8.2.2. Configuring the Remote Display Output, Continued

4. Using the **DOWN/UP** arrows, select the proper communication settings for your remote display, then press **ENTER**
5. Select the correct setting for your remote display, then press **ENTER**.
6. After **CHECKSUM** is displayed, **SETTINGS** is displayed again. Press the red traffic light button once to return to the weigh screen.

NOTE: Reference section [8.5. PROGRAMMING THE REMOTE DISPLAY](#) for additional information.

8.2.3. Selecting the Printer

1. When **DEVICE ATTACHED** displays, press **ENTER**.
2. Using the **DOWN/UP** arrows, select the desired printer, then press **ENTER**.

▪ OFF *	▪ TM-U230	▪ SP-2000
▪ TM-U295	▪ TM-U590	▪ SP-22000
▪ IDP-3550	▪ SP-700	▪ SP-298
▪ TM-U220		
- * Does not transmit weight amount.
3. When **LOAD DEFAULTS** display, press **ENTER**.
4. Using the **UP/DOWN** arrows, select **YES** or **NO**, then press **ENTER**.
5. When **SETTINGS** displays, press **ENTER**.
6. Using the **DOWN/UP** arrow, select the proper RS-232 Communication settings, then press **ENTER**.
7. The settings include Baud Rate, PARity, Stop Bits, Data Bits, and CheckSum.
8. Input the correct setting, then press **ENTER**.

NOTE: The Fairbanks Scales standard default COM Port settings for all the printers is **9600 Baud, No Parity, 8 Bits, and 1 Stop Bit**.

- The **FORMAT** option does not appear when programming the printers.
-

8.2.4. PC Data String Output

1. When **DEVICE ATTACHED** displays, press **ENTER**.
2. Pressing the **DOWN** arrow, select **PC CONTINUOUS** or **PC POLLED**, then press **ENTER**.
 - **PC CONTINUOUS** – Sends displayed weight continuously.
 - **PC POLLED** – The external device sends out a polling request (i.e. CR, “W”, etc.), and the instrument responds with return data.

*Data sent is configured in the **GTN** format as the **DEMAND OUTPUT**..*

3. Press **ENTER** when **FORMAT** displays.
4. Press the **DOWN**-arrow to select the correct standardized data string format.
 - **FAIRBANKS .**
 - **WEIGHTRONIX**
 - **TOLEDO**
 - **CONDEC**
 - **CARDINAL**
5. Press **ENTER** to confirm this selection.
6. When **LOAD DEFAULTS** displays, press **ENTER**.
7. Using the **DOWN/UP** arrow, select **YES** or **NO**, then press **ENTER**.
8. When **SETTINGS** displays, press **ENTER**.
9. Using the **DOWN/UP** arrow, select the proper RS-232 communication settings, then press **ENTER**.
 - The settings include BAUD, RATE, PARITY, STOP, BITS, DATA BITS, and CHECKSUM.
10. When the current setting is displayed, either press **ENTER**.

OR

Using the **Numeric Keypad** or **DOWN** arrow input the desired setting, then press **ENTER**.

8.2.5. Configuring Network Output

1. Press **MENU** and **LOGIN** will show on screen. Press **ENTER**, (Login in with appropriate login) **OK** appears. Press **ENTER** and **AUDIT TRAIL** appears.
2. Press **DOWN/UP** arrows until **CONFIGURATION** appears. Press **ENTER** and **CHANGE CUSTOMER PASSWORD** appears.
3. Press **DOWN/UP** arrows until **COM PORTS** appears. Press **ENTER**. **UCOM= 1** appears.
4. Press **DOWN/UP** arrows to select the appropriate COM= 1,2,3 or 4. Press **ENTER**. The selected comport, 1,2,3 or 4, is dedicated to the ethernet output

only. COM with the comport number you are using. (RS232) will show on the screen. PRESS **ENTER**.

5. Press **DOWN/UP** arrows until **DEVICE ATTACHED** appears. Press **ENTER**. **OFF** appears.
6. Press **DOWN/UP** arrows until **NETWORK** appears. Press **ENTER**, **LOCAL PORT** appears. Add the correct port number as determined by the customer. 5001 is the default. Press **ENTER**, **OK** appears and then **CONFIGURE**.
7. Press **ENTER**, **LOAD** appears. Press **ENTER**, **FAIRBANKS** appears. Press **UP/DOWN** arrows on keypad to view a list of formats. Choose the one the customer's IT department wants the FB6005 to stream to the PC. Press **ENTER**, **OK** appears and then **LOAD**.
8. To return to the weigh screen, press **MENU** several times **OR** press the **RED STOP LIGHT** button twice.

8.2.6. DemandPC

This option transmits the weight data in the **GTN format** whenever a carriage return is received.

- All data strings which have a **NON-ZERO VALUE** in the coordinates will be transmitted.
- The order the data strings appear in the data transmission follows the order in which the data is listed in the ticket format.

NOTE: DemandPC has a separate ticket format that must be enabled in the [Ticket Formats](#) menu.

Follow these steps to format the DemandPC option.

1. When **DEVICE ATTACHED** displays, press **ENTER**.
2. Pressing the **DOWN** arrow, select the **DEMANDPC OUTPUT** then press **ENTER**.
3. When **LOAD DEFAULTS** displays, press **ENTER**.
4. Using the **DOWN/UP** arrow, select **YES** or **NO**, then press **ENTER**.
5. When **SETTINGS** displays, press **ENTER**.
6. Using the **DOWN/UP** arrow, select the proper RS-232 communication settings, then press **ENTER**.
 - These settings include BAUD, RATE, PARITY, STOP, BITS, DATA BITS, and CHECKSUM.



7. When the current setting is displayed, either press **ENTER**.

OR...

Using the **numeric keypad** or **DOWN** arrow input the desired setting, then press **ENTER**.

8.3. 4-20mA Analog Card

The **4-20mA Expansion Card Accessory** is a 16 bit, high resolution, analog output, offering these two transmission options.

ACTIVE provides its own **18VDC** power source for the analog output circuit.

- The dedicated output interfaces the Instrument with PLC's, chart recorders, or other control systems requiring a 4-20mA signal.

ACTIVE, SUPPLIED POWER SOURCE	
4-20mA Specifications	16 bit resolution +/- .01 integral linearity
Current Loop Voltage Compliance	Fairbanks Instrumentation provides the scale's 18VDC power source.
Full Scale Setting Time	8mSecs
Output Impedance	25 Meg Ohms.
Alarm Current	3.5 to 24mA (underload/overload conditions), Offset at 25°C; +/- .1% of full scale. Offset drift; +/- 25 ppm of full scale per degree Celsius.
Total Output Error	(20mA) at 25°C: +/- .2% of full scale max
Total Output Drift	+/- 50 ppm of full scale per degree Celsius max

PASSIVE requires the customer supply the external power source of **7VDC to 40VDC**.

PASSIVE, CUSTOMER-SUPPLIED POWER SOURCE	
4-20mA Specifications	16 bit resolution +/- .01 integral linearity
Current Loop Voltage Compliance	The negative (-) power of the supply <i>MUST</i> be isolated from chassis ground. A separate power supply must be furnished for each installed passive 4-20.
Full Scale Setting Time	8mSecs
Output Impedance	25 Meg Ohms.
Alarm Current	3.5 to 24mA (underload/overload conditions), Offset at 25°C; +/- .1% of full scale. Offset drift; +/- 25 ppm of full scale per degree Celsius.
Total Output Error	(20mA) at 25°C: +/- .2% of full scale max
Total Output Drift	+/- 50 ppm of full scale per degree Celsius max



Requires minimum 100 Ohm resistance

8.3.1. Active 4-20mA Kit Installation (33258)

The **4-20 mA ANALOG CARD (33252)** is an **ACTIVE** current loop device with 16-Bit High Resolution Output.

1. Shut down the Instrument properly, and then unplug it.
2. Remove the cover.
3. Install the **Card Guides (29966)** onto the Expansion PCB Assembly.

- Note their orientation and location on the PCB Assembly, as they may be installed in any open slot.
 - The **4-20mA PCB Assembly** can be installed in any open location on the **Expansion PCB Assembly**.
4. Remove one of the **hole plugs** on the back of the FB6000, then replace this with a **Strain Relief Bushing (11020)**, used for the **4-20mA Interface Cable**..
 5. Connect the **Active 4-20mA Interface Cable** according to this chart.
 - Using a **100-150Ω Resister** is recommended to complete this circuit.



4-20MA INTERFACE	OUTPUT CONNECTION
Output (-)	TB2-2
Output (+)	TB2-3

6. Access the FB6000 Instrument's internal configuration to setup the Active 4-20mA PCB Assembly, in order to test and calibrate the output.
7. Reassemble the instrument, then place it into operation.

C A U T I O N

DO NOT CONNECT an **EXTERNAL POWER SUPPLY!**



Doing so will damage the **4-20mA Expansion Card**.

8.3.2. Passive 4-20mA Kit Installation (30919)

The **4-20 mA ANALOG CARD (30738)** is a **PASSIVE** current loop device with 16-Bit High Resolution Output.

1. **Shut down the Instrument properly, and then unplug it.**
2. Remove the cover.
3. Install the Card Guides (29966) onto the **Expansion PCB Assembly**.
 - Note their orientation and location on the PCB Assembly, as they may be installed in any open slot.

- The **4-20mA PCB Assembly** can be installed in any open location on the **Expansion PCB Assembly**.
- 4. Remove one of the **hole plugs** on the back of the FB6000, then replace this with a **Strain Relief Bushing (11020)**, used for the **4-20mA Interface Cable**..
- 5. Connect the **Passive 4-20mA Interface Cable** according to this chart.
 - Using a **100-150Ω Resistor** is recommended to complete this circuit.



4-20MA INTERFACE	OUTPUT CONNECTION
Output (+)	TB2-1
Output (-)	TB2-3

6. Access the FB6000 Instrument's internal configuration to setup the Passive 4-20mA PCB Assembly, in order to test and calibrate the output.
7. Reassemble the instrument, then place it into operation.



8.4. Traffic Light Control

The **Traffic Light Control** sets the operational modes of the traffic light. It is typically controlled automatically by the instrument weightment cycle.

Each **I/O RELAY CARD** supports **two (2)** sets of lights operated in parallel.

8.4.1. Control (Traffic Light)

Follow these steps to setup the **TRAFFIC LIGHT CONTROL**.

1. In the **CONFIGURATION MENU**, press the DOWN arrow until **TRAFFIC LIGHT CONTROL** displays.
2. Press **ENTER**.
3. When **SCALE ID 1** displays, press **ENTER**.
4. When **CONTROL TRAFFIC LIGHT** displays, press **ENTER**.
5. When **AUTOMATIC** displays, either press **ENTER** to select it,
6. Or...
7. Press the **DOWN** arrow to enter the **MANUAL** option, then press **ENTER**.

8.4.2. Event to Signal

Follow these steps to setup the **EVENT TO SIGNAL OPTION**.

1. In the **Configuration Menu**, press the **DOWN** arrow until **TRAFFIC LIGHT CONTROL** displays.
2. Press **ENTER**.
3. When **SCALE ID 1** displays, press **ENTER**.
4. Press the **DOWN** arrow until **CONTROL TRAFFIC LIGHT** displays, then press **ENTER**.
5. Press the **DOWN** arrow until **EVENT TO SIGNAL** displays, then press **ENTER**.
6. When **X SECOND TIME DELAY** displays, where "X" is the delay setting, input a value from **2** to **10** (seconds), then press **ENTER**.

Default = 6 Seconds

8.5. Programming the Remote Display

8.5.1. Display Mode

Follow these steps to setup the **DISPLAY MODE**.

1. In the **CONFIGURATION MENU**, press the DOWN arrow until **REMOTE DISPLAY** appears. Press **ENTER**.
2. When **DISPLAY MODE** appears, press **ENTER**.
3. When **CONTINUOUS** displays, either press **ENTER** to select it, or press the DOWN arrow to enter **ON PRINT**.
4. Press **ENTER**.

8.5.2. Type (Output)

This option formats what will appear on the **REMOTE DISPLAY**.

1. In the **REMOTE DISPLAY** menu, press the DOWN arrow until **TYPE OUTPUT** displays, then press **ENTER**.
2. Press the DOWN arrow to select Gross Wt, Net Wt, Ticket Number, Active Gross or Net Wt.
3. Press **ENTER**.

IMPORTANT PROGRAMMING CONSIDERATIONS

- When **Display mode** is set to **CONTINUOUS**, and the **Active Gross or NetWt** is also set, the remote display follows what appears on the instrument display.
- The operator can toggle between **Gross Wt** and **Net Wt** by pressing the **B/G NET** button.
- If the output type is set to **Gross Wt**, the instrument will only display the Gross Weight, regardless of what appears on the instrument.
- This is the same for **Net Wt**. The remote display indicates the Net Weight.
- When display **Type (Output)** is set to **TICKET NUMBER**, the next **Ticket Number** displays until a print occurs and the printed vehicle leaves the scale.
- The weight drops below a threshold, either the **Initial Weight** threshold entry or **25 divisions of zero**, whichever is higher.
- At that point, the next new ticket number displays.
- If display **Type (Output)** is set to **TICKET NUMBER**; the 1601/5/5T Remote Display must be configured first.
- Set the Annunciator (**ANNUN**) to **SCALE 1**.
- Set the Annunciator to **NO**.

8.5.3. Enable 1605T



Follow these steps to enable the 1605T Display Instrument.

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **REMOTE DISPLAY** appears, then press **ENTER**.
2. Press the **DOWN** arrow until **ENABLE 1605T** displays, then press **ENTER**.
3. Select **YES** or **NO**, then press **ENTER**.

NOTE: For the **Traffic Light** function on the 1605T to work, the **Display Mode** must be set to **CONTINUOUS**.

8.6. Basic Troubleshooting

ERROR CONDITION(S)	SOLUTION(S)
LOAD CELL FAILURE (S) Flashing and displays "-- -- -- --"	Possible load cell damage. Access the Load Cell Diagnostics Menu to verify the load cell status. Count stability or change of counts. Contact the local service for further trouble-shooting. Call for Service.
SC CELLS FOUND NONE	Possible damaged load cell cable. Load cell shortened. Defective Pit Power Supply. Defective Smart Sectional Controller(s). Defective SIC Module.
Displays "-- -- -- --" " " LB GROSS	Communication error to load Cells. Check settings by pressing F10 . Settings should be COM2, Even.
INTERR	System Error. Restore Backup, if possible to recover. Otherwise, replace the PCB Assembly Base Board (33143).
POWER SUPPLY ERROR: AC OUTPUT OPEN	Check main interface cable to be cut.
AC OUTPUT SHORTENED	Cable problems, usually repairable.
COMMUNICATION ERROR	Can be caused by numerous transmission problems, including bad Load Cell, faulty cable, conflicting programming, etc.
POWER SUPPLY NEEDS TO BE CONFIGURED: GO TO MENU	First-time opening message to configure the Instrument to the Power Supply.
Unable to select certain Loop ID's, or doesn't progress after entering the Loop ID's	Check for INCOMPLETE transaction/s stored with a NEGATIVE Gross weight. This happens when the scale is empty and bouncing around due to wind or whatever and the Operator creates an Inbound transaction. THIS PROCESS WILL DELETE ALL INCOMPLETE TRANSACTIONS! They will not be recoverable. It is critical to pay attention to step #1 below. To correct; 1. Make sure they no other Incomplete transactions they need to keep. THIS PROCESS WILL DELETE <u>ALL</u> INCOMPLETE TRANSACTIONS! 2. Go to Configuration Menu 3. Select TRANSACTION FILES 4. Select DELETE INCOMPLETES

SECTION 9: FORMATTING TICKETS

9.1. Standard Ticket Formatting Steps

Listed below are the standard steps for formatting a ticket.

1. Configure the **Service Menu** to the correct **OPERATING MODE**.

- This setup determines how the ticket prints.

The **GTN format** configures only the **GTN tickets**.

The **In/Out format** configures In/Out tickets.

The **Basic format** configures BasicIn and BasicOut tickets.

Each **Operating Mode** formats the weighment data in different positions on the ticket, printing only the needed data for that ticket.

The ticket format can also vary due to the printer type that is used.

Each ticket format can be adjusted to best suit the customer's needs.

IMPORTANT NOTE: *Always configure the **COM Ports** before formatting tickets.*

2. Set up the **COM Ports** in the **Configuration Menu** to a specific attached device.

3. Install, wire and configure the printer.

4. Access the **TICKET FORMAT** menu.

5. Insert a blank ticket, then press the **PRINT** key for a ticket self-test.

- This identifies its current margin setup.

6. Press the **OUT** button to print out the complete **Mode of Operation** format structure.

7. Using this self-test ticket, plan where to format the ticket margins and available print spaces.

- Determine how the current ticket format might differ from the customer's needs.
- Plan the needed changes according to their **SPACE** (*horizontal*) and **FEED** (*vertical*) coordinates of the ticket.
- Mark up this ticket with a ruler and pencil as needed, using it as a guide.


Error Condition	Solution(s)
Unable to select certain Loop ID's, or doesn't progress after entering the Loop ID's	<p>Check for INCOMPLETE transaction/s stored with a NEGATIVE Gross weight.</p> <p>This happens when the scale is empty and bouncing around due to wind or whatever and the Operator creates an Inbound transaction.</p> <p>THIS PROCESS WILL DELETE ALL INCOMPLETE TRANSACTIONS!</p> <p>They will not be recoverable.</p> <p>It is critical to pay attention to step #1 below.</p> <p>To correct;</p> <ol style="list-style-type: none"> 5. Make sure they no other Incomplete transactions they need to keep. THIS PROCESS WILL DELETE <u>ALL</u> INCOMPLETE TRANSACTIONS! 6. Go to Configuration Menu 7. Select TRANSACTION FILES 8. Select DELETE INCOMPLETES

9.2. Printer and Ticket Differences

Consider these factors for placement of data when formatting a ticket.

A. TOP MARGIN


The area between the ticket sensor, stop, tear-off and the first line of print is called the **Top Margin**. Printing is not possible in this part of the ticket.



B. PRINTING AREA

There is a wide variation of printing area used between the different types of printers. This is determined by the physical characteristics of each particular one.


To find the available space on a ticket, run a printer self-test.



**TM-U295
Ticket Printer**

1.0
Inch

2.70 Inches



TM-U590 Ticket Printer

1.0
Inch

5.25 Inches

The print head size is different between these two models, so their print area is different also.

C. ENHANCED PRINT SIZE

Another factor that regulates how many lines can be placed on a ticket is the font size of the characters. This varies depending on the printer.

- Typically, the **Enhanced Print** feature doubles the standard default font size, making it bolded and emphasized on the page.
- It is recommended using Enhanced Print for only the most important characters on the ticket, such as **Truck ID**, **Net Weight**, etc.
- It also enhances the character size of **FEEDS** and **SPACES**.

9.3. Programming Tips

Follow these guidelines when programming a **TICKET FORMAT**.

- All commands are written in the specific order to the ticket. They flow downward, starting from the top-left of the printer-assigned margin.
- Each command first describes the action, then in brackets, it defines how many, the type of action, or exactly what text to print.
- To remove a printed item on the ticket, display the command, then press the **ZERO** key.

9.3.1. Write Commands

WRITE (____) commands offer a standard list of **System Data Fields** to use when programming.

Follow these steps to alter how a **WRITE** field appears.

- Use the **UP/DOWN** arrows to navigate thru the **WRITE** commands, then press **ENTER** to open one.

2. Using the **UP/DOWN arrows**, select the option that best suits the programming need, then press **ENTER**.
3. The **WRITE (----)** option selected will display next on the ticket.
4. Certain commands offer two choices, followed by a printed response for one.

Example:

HIDEWRITEONZERO (TARE/TARE)

This example means the following:

- *Hide (do not print) the Tare amount if it equals ZERO (0).*
- *Write (print) the Tare amount if it is greater than ZERO (0).*

Keypad Formatting Buttons

UNITS: Inserts new format line *before*.

B/G/NET: Inserts new format line *after*.

ZERO: Deletes the current format line.

OUT: Prints entire Format Script.

MENU: Saves ticket format.
Steps back one level.

ENTER: Saves all data input..

PRINT: Prints a sample ticket.

RED Button: Exits to **Weigh Screen**.

GREEN Button: Deletes Format Script.

9.3.1. Write Commands, Continued

Listed below are the **WRITE (_____)** commands.

GROSS	TICKET NUMBER	DUALGROSS
TARE	LOOPIDTEXT	DUALTARE
NET	LOOPIDPROMPT 1TEXT	DUAL NET
DATEIN	PROMPT 1	DUALINBOUND
DATEOUT	INBOUND	DUALUNITSGROSS
TIMEIN	MANUAL TARE	DUTANTUNITS
TIMEOUT	DUPLICATE	VEHDESC
UNITSGROSS		
UNITSTARENET		

WRITE (TEXT) commands are programmable text fields, allowing legends or prompts to be altered to suit the application needs.

These text fields can be any character(s) required to suit the customer's need.

All data items are **left justified**, with a maximum of **fifteen (15) characters**.

NOTE: When inverting tickets, the **Invert "On"** command should be the first one in the format.

Turn the option **"Off"** as the last command before the ticket release, or the reports will invert when they print.

9.3.2. Quick Formatting Buttons

KEYPAD	EXT. KEYBOARD	PROGRAMMING FUNCTION	NORMAL FUNCTION
ZERO	DEL	Deletes current formatting line.	ZERO
UNITS	PgUp	Inserts a new line before the current line.	UNITS
PRINT	INSERT	Prints a sample ticket	PRINTS
B/G NET	END	Inserts a new line after the current line.	B/G NET Select
MENU	HOME	<ul style="list-style-type: none"> Saves ticket format (YES/NO). Backs up one menu level. 	MENU
RED LIGHT	F1	Exits without saving.	Red Light ON
GREEN LIGHT	F2	Deletes the entire Ticket Format Script.	Green Light ON
IN	F4	N/A	INBOUND
OUT	F5	Prints the entire Ticket Format Script.	OUTBOUND
TARE	“.”	N/A	Auto Tare

9.3.3. Ticket Format Commands

The **TICKET FORMAT** commands are defined below.

SPACE ()	One (1) movement across (horizontal).
FEED ()	One (1) movement downward (vertical).
INVERT ON/OFF	Prints the ticket from the bottom-to-the-top, placing data where it belongs according to the programmed coordinates.
WRITE TEXT ("___")	Programmable fields that allow Legends or Prompts to be altered to suit the application needs. Appears exactly as written within the quotation marks. <i>When programming (WRITE) fields, a System Data list displays.</i>
HIDEWRITEONZERO (TARE, NET)	If the Tare is ZERO , this prevents the Net Weight figure from being printed.
HIDEWRITETEXTONZERO (___/"___")	HIDE the message if the amount is ZERO (0) . WRITE the quoted word if there is a different amount. <i>Quotation marks within the command display the exact words.</i>
WRITE (_____)	Without quotation marks, the printer writes out requested data of the command. <i>A command is sometimes blended with others together to print all the correct elements. WRITE (UNITSTARENET) is an example.</i>
WRITE (DUPLICATE)	"Duplicate Copy" appears on the ticket for a TICKET REPRINT . <i>This specialized command has one purpose, and cannot be altered.</i>
ENHANCE ("on")	Enlarges the font characters, and prints them in bold text.
ENHANCE ("off")	Reduces the font size, and prints them in standard text.
WRITE (GROSS)	Prints the Gross Weight .
WRITE (TARE)	Prints the Tare Weight .
WRITE (NET)	Prints the Net Weight .
WRITE (DATE IN)	Prints the date of the first weighment .
WRITE (DATE OUT)	Prints the date of the final weighment .
WRITE (TIME IN)	Prints the time of the first weighment .
WRITE (TIME OUT)	Prints the time of the final weighment .
WRITE (UNITS)	Prints the Unit choice.
WRITE (TICKET NUMBER)	Prints the current ticket number .
WRITE (LOOP ID TEXT)	Prints the legend in the Loop ID field, determined by the technician. <i>Truck Number, Rail Car Number, etc.</i>
WRITE (LOOP ID)	Prints the Loop ID .
WRITE (PROMPT 1 TEXT)	Prints the Legend that prompts the user to enter an answer or to add data. <i>BOL Number, License, etc.</i>
WRITE (PROMPT 1)	Prints the data from the Prompt 1 Text field.
INBOUND	Prints the Inbound weight .
WRITE (MANUAL TARE)	Prints an asterisk (*) next to the TARE value when it is a MANUAL TARE..
RELEASE ()	End of the ticket, this command releases the ticket from the printer.
CLAMP ()	Clamps the printer paper.
CUTPAPER ()	Cuts the printer paper.

9.3.4. Ticket Formats

*Follow these steps to set up and configure the **TICKET FORMATS**.*

1. In the **CONFIGURATION MENU**, press the **DOWN arrow** until **TICKET FORMATS** displays, then press **ENTER**.
 2. When **PRINTER** displays, select the desired available printer.

If the printer is already selected, then press **ENTER**,

OR...

Press the **DOWN arrow** to select the correct printer, then press **ENTER**.
 3. When **SELECT FORMAT** displays, press the **DOWN arrow** to select one of the five (5) default **Ticket Formats**, then press **ENTER**.
 - **GTN**
 - **INBOUND**
 - **OUTBOUND**
 - **BASICIN**
 - **BASICOUT**
 4. Press the **DOWN arrow** to enter either **DISABLED** or **ENABLED**, then press **ENTER** to confirm this selection.
 5. When **FORMAT** displays, press **ENTER**.
 6. Press the **UP/DOWN arrows** to navigate and format these ticket commands.
 - Press the **PRINT key** while in the **TICKET FORMAT mode** to print a test ticket.
 - Adjust the parameters for **FEED** and **SPACE** to align the information as required to fit the ticket.
 - Align and fit all the needed information on it. Repeat this process as needed, until all the data prints correctly on the ticket.
 - Remove a printed item from the ticket by pressing the **ZERO** key.
- Keypad Formatting Buttons**
UNITS: Inserts new format line **units**.
B/G/NET: Inserts new format line **base/gross/net**.
ZERO: Deletes the current format line.
OUT: Prints entire Format Script.
MENU: Saves ticket format.
Steps back one level.
ENTER: Saves all data input..
PRINT: Prints a sample ticket.
RED Button: Exits to **Weigh Station**.
GREEN Button: Deletes Format Script.

Keypad Formatting Buttons

UNITS: Inserts new format line *before*.

B/G/NET: Inserts new format line *after*.

ZERO: Deletes the current format line.

OUT: Prints entire Format Script.

MENU: Saves ticket format.

Steps back one level.

ENTER: Saves all data input..

PRINT: Prints a sample ticket.

RED Button: Exits to Weigh Screen.

GREEN Button: Deletes Format Script.

9.3.5. G/T/N Ticket Formatting

Defined below is the structure and appearance of a **GROSS/TARE/NET** ticket.





Diagram illustrating the structure and appearance of a G/T/N Ticket. The ticket is titled "WEIGHED ON A FAIRBANKS SCALE". It includes a "Duplicate Copy" label and a "TICKET NUMBER" field. The ticket displays weight measurements: "35020 lb GROSS", "12360 lb TARE", and "22660 lb NET". The date and time are "10/18/12" and "02:58 PM". The ticket is marked with "Enhance <on>" and "Enhance <off>" labels. The bottom of the ticket is labeled "FAIRBANKS SCALE CAT. 96757".

Callouts:

- X/Y axis starting point.** (Indicated by a blue arrow pointing to the top-left corner of the ticket area.)
- 1-Space <8> moves the ticket text horizontally.** (Indicated by a blue arrow pointing to the "TICKET NUMBER" field.)
- 3-Feed <1> moves the ticket text vertically.** (Indicated by a blue arrow pointing to the "TICKET NUMBER" field.)
- "Duplicate Copy" appears only when a TICKET REPRINT is performed.** (Indicated by a blue arrow pointing to the "Duplicate Copy" label.)

This image shows the printed areas and other defined elements of a G/T/N Ticket.

- All grey markings are for illustration purposes only.



Example of an actual G/T/N Ticket. The ticket is titled "WEIGHED ON A FAIRBANKS SCALE". It includes a "Duplicate Copy" label and a "TICKET NUMBER" field. The ticket displays weight measurements: "35020 lb GROSS", "12360 lb TARE", and "22660 lb NET". The date and time are "10/18/12" and "02:58 PM". The ticket is marked with "Enhance <on>" and "Enhance <off>" labels. The bottom of the ticket is labeled "FAIRBANKS SCALE CAT. 96757".

Fields:

- CUSTOMER'S NAME _____
- ADDRESS _____
- COMMODITY _____
- CARRIER _____
- INBOUND DATE _____ TIME _____
- OUTBOUND DATE 10/18/12 TIME 02:58 PM
- 35020 lb GROSS
- 12360 lb TARE
- 22660 lb NET
- DRIVER ON _____ OFF _____
- SHIPPER _____
- WEIGHER _____

Example of an actual G/T/N Ticket.

GTN	
1-Space <4>	
2-Write <Duplicate >	
3-Feed <1>	
4-WriteText <"TICKET NUMBER" >	
5-Space <6>	
6-Write <TicketNumber >	
7-Feed <14>	
8-Space <4>	
9-Write <DateOut >	
10-Space <10>	
11-Write <TimeOut >	
12-Feed <2>	
13-Enhance <"on" >	
14-Write <GroSS >	
15-Space <1>	
16-Write <UnitSGroSS >	
17-Space <1>	
18-WriteText <"GROSS" >	
19-Feed <1>	
20-Write <Tare >	
21-Space <1>	
22-Write <UnitSTareNet >	
23-Write <ManualTare >	
24-HideWriteTextOnZero <Tare, "TARE" >	
25-Feed <1>	
26-Write <Net >	
27-Space <1>	
28-Write <UnitSTareNet >	
29-Space <1>	
30-HideWriteTextOnZero <Tare, "NET" >	
31-Feed <2>	
32-Enhance <"off" >	
33-Feed <10>	
34-Release < >	

The flow chart above outlines the coordinates for each element of the G/T/N Ticket.

9.3.6. Inbound Ticket Formatting

Defined below is the structure and appearance of an **INBOUND** ticket example.

X/Y axis
starting point.

FAIRBANKS SCALES KC, MO 1-800-821-3322

WEIGHED ON A FAIRBANKS SCALE

Duplicate Copy

Enhance <"on"> INBOUND 25020 lb
LOOP ID 333
Enhance <"off"> 01/18/14 05:22 PM
Release

FAIRBANKS SCALE CAT. 96757

"Duplicate Copy"
appears *only* when a
TICKET REPRINT is
performed.

INBOUND	
1-Space <4>	
2-Write <Duplicate >	
3-Feed <1>	
4-Feed <10>	
5-WriteText <"INBOUND" >	
6-Space <6>	
7-Write <Inbound >	
8-Space <6>	
9-Write <UnitSGroSS >	
10-Feed <1>	
11-Write <LoopIDText >	
12-Space <6>	
13-Write <LoopID >	
14-Feed <2>	
15-Space <4>	
16-Write <DateIn >	
17-Space <10>	
18-Write <TimeIn >	
19-Feed <16>	
20-ReleaSe < >	

The image above shows the printed areas and other defined elements of the ticket.

- All grey markings are for illustration purposes only, and not printed.

FAIRBANKS SCALES KC, MO 1-800-821-3322

WEIGHED ON A FAIRBANKS SCALE

Duplicate Copy

CUSTOMER'S NAME _____

ADDRESS _____

COMMODITY _____

CARRIER _____

INBOUND
Loop ID

35020
333

lb

INBOUND DATE 10/18/12

TIME 03:00 PM

OUTBOUND DATE

TIME

DRIVER ON _____ OFF _____

SHIPPER _____

WEIGHER _____


FAIRBANKS SCALE CAT. 96757

Example of an **Inbound Ticket**.

The flow chart above outlines each element of the Inbound Ticket.

9.3.7. Outbound Ticket Formatting


Defined below is the structure and appearance of an **OUTBOUND** ticket example.



The diagram shows a printed ticket with various fields and a coordinate system. A blue box with a dashed arrow points to the top-left corner of the ticket, labeled "X / Y axis starting point." The ticket content includes:

- FAIRBANKS SCALES KC, MO 1-800-821-3322
- WEIGHED ON A FAIRBANKS SCALE
- Duplicate Copy
- TICKET NUMBER 15
- 10/18/12 05:22 PM
- Enhance <"on"> 49980 lb GROSS
- 35020 lb TARE
- 14960 lb NET
- Enhance <"off"> LOOP ID 333
- Release
- FAIRBANKS SCALE CAT. 96757

This image shows the printed areas and other defined elements of the **Outbound Ticket**.
 – All grey markings are for illustration purposes only.



The actual image of an Outbound Ticket shows the following fields:

- FAIRBANKS SCALES KC, MO 1-800-821-3322
- WEIGHED ON A FAIRBANKS SCALE
- TICKET NUMBER 15
- CUSTOMER'S NAME _____
- ADDRESS _____
- COMMODITY _____
- CARRIER _____
- INBOUND DATE 10/18/12 TIME 05:22 PM
- OUTBOUND DATE 10/18/12 TIME 05:22 PM
- 49980 lb GROSS
- 35020 lb TARE
- 14960 lb NET
- LOOP ID 333
- DRIVER ON _____ OFF _____
- SHIPPER _____
- WEIGHER _____
- FAIRBANKS SCALE CAT. 96757

Actual image of an **Outbound Ticket**
 (without any Inbound Ticket information).

OUTBOUND	
1-Space <4>	
2-Write <Duplicate >	
3-Feed <1>	
4-WriteText <"TICKET NUMBER" >	
5-Space <6>	
6-Write <TicketNumber >	
7-Feed <14>	
8-Space <4>	
9-Write <DateOut >	
10-Space <10>	
11-Write <TimeOut >	
12-Feed <2>	
13-Enhance <"on" >	
14-Write <GroSS >	
15-Space <1>	
16-Write <UnitSGroSS >	
17-Space <1>	
18-WriteText <"GROSS" >	
19-Feed <1>	
20-Write <Tare >	
21-Space <1>	
22-Write <UnitSTareNet >	
23-Write <ManualTare>	
24-HideWriteTextOnZero <Tare, "TARE" >	
25-Feed <1>	
26-Write <Net >	
27-Space <1>	
28-Write <UnitsTareNet >	
29-Space <1>	
30-HideWriteTextOnZero <Tare, "NET" >	
31-Feed <2>	
32-Enhance <"off" >	
33-Write <LoopIDText >	
34-Space <6>	
35-Write <LoopID >	
36-Feed <10>	
37-Release <>	

This flow chart outlines coordinates for each element of the **Outbound Ticket**.

9.3.8. Completed Transaction Ticket Example

Shown below is a ticket example of a completed **INBOUND / OUTBOUND** transaction.

INBOUND TICKET
includes the **LOOP ID**,
DATE, **TIME**, and Initial
Weight.

FAIRBANKS SCALES KC, MO 1-800-821-3322

WEIGHED ON A FAIRBANKS SCALE

TICKET NUMBER 12

CUSTOMER'S NAME _____

ADDRESS _____

COMMODITY _____

CARRIER _____

INBOUND 20000 1b
Loop ID 333

INBOUND DATE 10/18/12 TIME 02:54 PM
OUTBOUND DATE 10/18/12 TIME 04:24 PM
35020 1b GROSS
20000 1b TARE
15020 1b NET
Loop ID 333

DRIVER ON _____ OFF _____

SHIPPER _____

WEIGHER _____

FAIRBANKS SCALE CAT. 96757

OUTBOUND TICKET includes
the **DATE**, **TIME**, **GROSS**,
TARE and **NET** Weights. Also
includes the **TICKET NUMBER**
and **LOOP ID** NUMBER.

Keypad Formatting Buttons

UNITS: Inserts new format line *before*.

B/G/NET: Inserts new format line *after*.

ZERO: Deletes the current format line.

OUT: Prints entire Format Script.

MENU: Saves ticket format.

Steps back one level.


ENTER: Saves all data input..

PRINT: Prints a sample ticket.

RED Button: Exits to **Weigh Screen**.

GREEN Button: Deletes Format Script.

9.3.9. BasicIn and BasicOut Ticket Formatting



This image shows the printed areas and other defined elements of the **BasicIn** and **BasicOut** Tickets.


BASICIN	
1-Write <TimeIn >	
2-Space <1>	
3-Write <DateIn >	
4-Space <1>	
5-Write <GroSS >	
6-Space <1>	
7-Write <UnitSGroSS >	
8-Space <1>	
9-WriteText <"GROSS" >	
10-Feed <1>	
11-ReleaSe < >	

BASICOUT	
1-Feed <2>	
2-Space <1>	
3-Write <TimeOut >	
4-Space <1>	
5-Write <DateOut >	
6-Space <1>	
7-Write <GroSS >	
8-Space <1>	
9-Write <UnitSGroSS >	
10-Space <1>	
11-WriteText <"TARE" >	
12-Feed <1>	
13-ReleaSe < >	

NOTE: Tickets programmed in the **BasicIn** and **BasicOut** formats can be set up as the customer requests, within the boundaries of the ticket size.

– The one displayed above is shown as an **example only**.

9.3.10. Deleting a Ticket Format



Follow these steps to **DELETE** a ticket format, and then reset to the **factory default**.

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **TICKET FORMATS** displays, then press **ENTER**.
2. When **PRINTER** displays, press **ENTER**.
3. Press the **DOWN** arrow until the desired printer displays, then press **ENTER**.
4. Press the **DOWN** arrow until **SELECT FORMAT** displays, then press **ENTER**.
5. Press the **DOWN** arrow the **Ticket Format** to be deleted displays, then press **ENTER**.
6. When **ENABLED** or **DISABLED** displays, press **ENTER**.
7. Press the **DOWN** arrow until **DELETE** displays, then press **ENTER**.
8. Press the **DOWN** arrow until **YES** displays, then press **ENTER** to delete the current ticket format and replace with the default format.

9.4. Formatting Web Interface Tickets

9.4.1. Logging In to the Web Interface

1. Locate the IP Address of the FB60XX Series Instrument
(See [To obtain the current IP address of the FB60XX](#))

NOTE: In order to login to the Web Interface, you **MUST** logout of the FB60XX instrument. If you are **NOT** logged out, you will receive the message “**Front Panel in Use**” until you log out.

- Input the correct IP Address of the FB60XX into the Address Bar of the web browser, then press **ENTER** on the remote computer.



- Click on the **LOGIN** link.

- Input the **Default Service Password**, then press the **LOGIN** button.

Service Password = 2.


The Web Interface Home screen appears.

After you are logged in successfully, the message “*Remote Config in Process*” will appear on the screen of the instrument.




9.4.2. Ticket Format

- Click the drop-down arrow and **Select a printer**.
- Click the drop-down arrow and **Select a mode**.



IMPORTANT NOTE: The printer must be configured in the **COM Port menu** before it is available here.

3. Click the **EDIT FORMAT** button.
4. Drag-and-Drop the **FIELDS** options into their place on the **TICKET LAYOUT** area.
5. To add or delete lines within the ticket format, click the **+ ADD LINE** or **- REMOVE LINE**.
6. Once formatting is complete, click **TEST PRINT** to print a sample.
7. Either **SAVE** or **DELETE** the format.



FB6000 Home Log Help

MAIN MENU

Home

Logout

CONFIGURATION MENU

Ticket Format

Ticket Format: TM-U295 / GTN

Fields

Gross

Tare

Net

DateIn

DateOut

TimeIn

TimeOut

UnitsGross

UnitsTareNet

TicketNumber

LoopIDText

LoopID

Prompt1Text

Inbound

ManualTare

Duplicate

DualGross

DualTare

DualNet

DualInbound

DualUnitsGross

DuTaNUUnits

VehDesc

Text

FF

Release

Clamp

OutPaper

Ticket Layout

Options

(DUPLICATE COPY)

TICKET NUMBER 10000

6/19/14 03:52 PM

6/19/14 03:52 PM

00000000 1b GROSS

11111111 1b TARE

22222222 1b NET

+ Add Line

Line Count: 31

- Remove Line

Save Test Print Delete

Once completed,
click **TEST PRINT**.
Click either **SAVE**
or **DELETE**.

Drag-and-drop the
FIELDS options into
their place on the
TICKET LAYOUT
area.

The printed ticket
will appear similar to
how it is formatted.

To add or delete
lines within the ticket
format, click
+Add Line or **-
Remove Line**.

The image above displays a ticket with the
default **GTN** format using a **TM-U295** printer.

9.4.3. Standard Default Formats

Shown below are images of the **standard default formats** for each of the Ticket Modes when using the TM-U295.

Ticket Format: TM-U295 / GTN

Fields	Ticket Layout	Options
Gross	(DUPLICATE COPY)	
Tare	TICKET NUMBER 10000	
Net		
DateIn	6/19/14 03:52 PM	
DateOut		
TimeIn		
TimeOut		
UnitsGross		
UnitsTareNet		
TicketNumber		
LoopIDText		
LoopID		
Prompt1Text		
Prompt1		
Inbound		
ManualTare		
Duplicate	6/19/14 03:52 PM	
DualGross		
DualTare	0000000 1b GROSS	
DualNet	1111111 1b TARE	
DualInbound		
DualUnitsGross	2222222 1b NET	
DuTaNUUnits		
VehDesc		
Text		
FF		
Release		
Clamp		
CutPaper		

Line Count: 31

Save Test Print Delete

Ticket Format: TM-U295 / Inbound

Fields	Ticket Layout	Options
Gross	(DUPLICATE COPY)	
Tare		
Net		
DateIn		
DateOut		
TimeIn		
TimeOut		
UnitsGross		
UnitsTareNet		
TicketNumber		
LoopIDText		
LoopID		
Prompt1Text	INBOUND 0000000 1b	
Prompt1	Loop ID <LoopID>	
Inbound		
ManualTare	6/19/14 03:55 PM	
Duplicate		
DualGross		
DualTare		
DualNet		
DualInbound		
DualUnitsGross		
DuTaNUUnits		
VehDesc		
Text		
FF		
Release		
Clamp		
CutPaper		

Line Count: 30

Save Test Print Delete

Ticket Format: TM-U295 / Outbound

Fields	Ticket Layout	Options
Gross	(DUPLICATE COPY)	
Tare	TICKET NUMBER 10000	
Net		
DateIn		
DateOut		
TimeIn		
TimeOut		
UnitsGross		
UnitsTareNet		
TicketNumber		
LoopIDText		
LoopID		
Prompt1Text		
Prompt1		
Inbound		
ManualTare		
Duplicate	6/19/14 03:57 PM	
DualGross		
DualTare	0000000 1b GROSS	
DualNet	1111111 1b TARE	
DualInbound		
DualUnitsGross	2222222 1b NET	
DuTaNUUnits		
VehDesc		
Text		
FF		
Release		
Clamp		
CutPaper		

Line Count: 31

Save Test Print Delete

Ticket Format: TM-U295 / BasicIn

Fields	Ticket Layout	Options
Gross	03:58 PM 6/19/14 0000000 1b GROSS	
DateIn		
TimeIn	[Release]	
UnitsGross		
Prompt1Text		
Prompt1		
DualGross		
DualUnitsGross		
Text		
FF		
Release		
Clamp		
CutPaper		

Line Count: 1

Save Test Print Delete

Ticket Format: TM-U295 / BasicOut

Fields	Ticket Layout	Options
Gross		
DateOut		
TimeOut	03:59 PM 6/19/14 0000000 1b TARE	
UnitsGross		
Prompt1Text	[Release]	
Prompt1		
DualGross		
DualUnitsGross		
Text		
FF		
Release		
Clamp		
CutPaper		


Line Count: 3

Save Test Print Delete

9.4.4. Exiting Without Saving


There are two warnings that display when the ticket format is closed without being saved.

DELETE BUTTON pressed without saving the format identifies the action.



CLOSING THE PROGRAM WITHOUT SAVING offers three buttons.

- **CANCEL** returns to the Ticket Interface.
- **SAVE BEFORE LEAVING** saves the format before exiting the interface.
- **JUST LEAVE (CHANGES WILL BE LOST)** closes the Ticket Interface without saving the current format.



APPENDIX I: DATA STRING OUTPUTS

A. Remote Display Output

DATA FORMAT

<STX><A><0><SP/-><XXXXXX><ETX>

NOTES:

1. Characters denoted by X are characters 0-9.
 2. Leading zeroes are suppressed.
 3. Polarity indication for a positive value is a space (SP).
 - Negative values are not transmitted.
 4. Identifier code <4><0> = Gross weight.
 - Transmission is Gross Only.
 5. Transmission for the DEMAND Mode occurs when a carriage return (CR) HEX 0D is received.
 6. See [APPENDIX V](#) for more ID Codes.
-

B. Configure Output

The Continuous Computer Output is an uninitiated, unrequested output that gets transmitted at a fixed time interval.

FAIRBANKS/TOLEDO DATA FORMAT

<STX><A><C><GGGGGG><TTTTTT><CR>

Character String Description:

STX - Start of Text character (02 Hex)

A - Status Word A

B - Status Word B

C - Status Word C

G (gross weight data) - xxxxxx Displayed Weight : x = Weight

6 characters if the graduation size does not have a decimal point.

5 characters if the graduation size does have a decimal point.

The decimal point is not sent as part of the character string.

T (tare weight data) - xxxxxx Tare Value : x = Tare

(6 characters if the graduation size does not have a decimal point.)

(5 characters if the graduation size does have a decimal point.

The decimal point is not sent as part of the character string.

CR - Carriage Return Character: (0D hex)

CS - CheckSum Character: If enabled, this character consists of the last eight bits of the binary sum of all characters transmitted up to this checksum character.

B. Configure Output, Continued

STATUS CODE (WORD) A

Bit #	X00	X0	X	X.X	X.XX	X.XXX	X.XXXX	X.XXXXX
0	0	1	0	1	0	1	0	1
1	0	0	1	1	0	0	1	1
2	0	0	0	0	1	1	1	1

FAIRBANKS/TOLEDO DATA FORMAT

INCREMENT SIZE

Bit #		Count By 1		Count by 2		Count by 5
3		1		0		1
4		0		1		1
5				Always Logic 1		
6				Always Logic 0		
7				Parity Bit		

STATUS CODE (WORD) B

Bit #	Description			
0		Gross = 0		Net = 1
1		Positive = 0		Negative = 1
2		In Range = 0		Overcapacity = 1
3		No Motion = 0		Motion = 1
4		Lb = 0		Kg = 1
5		Always Logic 1		
6		Normal = 0		Power Up = 1
7		Parity Bit		

B. Configure Output, Continued

STATUS CODE (WORD) C

Bit #	Description			
0		Always Logic = 0		
1		Always Logic = 0		
2		Always Logic = 0		
3		Normal = 0		Print Switch Pushed = 1
4		Always Logic = 0		
5		Always Logic = 0		
6		Normal = 0		Keyboard Tare = 1
7		Parity Bit		

CARDINAL 738 CONTINUOUS SCOREBOARD DATA FORMAT

<CR><P><WWWWW>Period (.)<m><SP><u><SP><g><SP><SP><ETX>

Character String Description:

CR – Carriage return

P – Polarity (+ = Positive weight, - = Negative weight)

W – Displayed weight

- 6 characters if the graduation size does not have a decimal point.

- 5 characters if the graduation size does have a decimal point.

m – Motion or o = Overload

SP – Space

U - Units (lb = pounds, kg = kilograms)

g – Gross or **n** = Net

ETX - End of text

- Leading zeros are not suppressed
- If division size has no decimal point, set the decimal to "trailing".
- If division size has a decimal point, set the decimal to "floating".

B. Configure Output, Continued

WEIGHTRONIX DATA FORMAT

<SP><G><WWWWW><SP><U><U><CR><LF>

Character String Description:

SP – Space

g – Gross or **n** = Net

W – Displayed weight

- 6 characters if the graduation size does not have a decimal point.
- 5 characters if the graduation size does have a decimal point.

SP – Space

U – Units (lb = pounds, kg = kilograms)

M – Motion

CR – Carriage return

LF – Line feed

- Leading zeros are not suppressed.
 - There is no motion character.
-

CONDEC CONTINUOUS DATA FORMAT

<STX><SP><SP><WWWWW><U><G><M><CR>

Character String Description:

STX – Start of Text character (02 Hex)

SP – Space

SP – Space

W – Displayed weight

- 6 characters if the graduation size does not have a decimal point.
- 5 characters if the graduation size does have a decimal point.

U – Units (L = pounds, K = kilograms)

G – Gross; **N** = Net

M – Motion

CR – Carriage return.

- Leading zeros are suppressed.
-

APPENDIX II: REMOTE SERIAL COMMANDS

COMMAND	DESCRIPTION
A	Sets the <u>A</u> uto Tare Weight on scale.
G	Turns the traffic light <u>G</u> reen. <ul style="list-style-type: none">▪ Used in Manual Mode only.
LA	Changes Traffic <u>L</u> ight to Automatic Mode .
LM	Changes Traffic <u>L</u> ight to Manual Mode .
R	Turns Traffic Light <u>R</u> ed. <ul style="list-style-type: none">▪ Used in the Manual Mode only.
Txxxxx	Sets <u>T</u> are on scale <ul style="list-style-type: none">▪ Where xxxxx equals the tare weight value required.
U	Toggles <u>U</u> nits on scale.
Z	<u>Z</u> eroes the scale.
P	<u>P</u> rints a ticket for the active scale.
W	Demand Request for a <u>W</u> eight output using PC Polled .

APPENDIX III: CONNECTING TO THE FB60XX VIA ETHERNET

Connecting via the Web Utility using an ethernet crossover cable

NOTE: If you are not using a keyboard and mouse on your PC or if you are using a Tablet, touch and hold will act as a 'Right Click'.

To access the current IP address of the FB60XX:

1. Login to the FB60XX
2. Scroll down to **CONFIGURATION**.
Press ENTER
3. Scroll up to **NETWORK**
Press ENTER
4. Use **DHCP?** is displayed.
Press ENTER
Depending on how the FB60XX has been configured **DHCP** or **STATIC** will display. Follow the instructions below for **DHCP** or **STATIC**:

If DHCP is displayed...

5. Scroll down to **STATIC** and press ENTER:
6. Use **DHCP?** is displayed.
Scroll down to **STATIC IP** and press ENTER
7. **IP ADDRESS** is displayed
Enter the IP ADDRESS as:
192.168.100.XXX and press ENTER
XXX must be **greater** than 001
8. **IP ADDRESS** is displayed and press ENTER
9. Scroll down to **NETMASK** and press ENTER
Enter the **NETMASK** as:
255.255.255.000 and press ENTER
10. Scroll down to **GATEWAY** and press ENTER
Enter the **GATEWAY** as:
192.168.100.001 and press ENTER

11. Scroll down to **PRIMARY DNS** and press ENTER
Enter the **PRIMARY DNS** as:
008.008.008.008 and press ENTER
12. Scroll down to **APPLY CHANGES**
Scroll down to **YES** and press ENTER
13. Press the **RED** Traffic light button twice to return to the weigh screen

If STATIC is displayed...

5. Press ENTER
6. **IP ADDRESS** is displayed and press ENTER
7. The FB60XX IP address is displayed
XXX.XXX.XXX.XXX
8. Use the right arrow to scroll to see the whole IP address
9. Write down the IP address


Procedure:

1. **FOR TABLET USERS ONLY** - Plug in your USB to ethernet adaptor
 - a. If you are using a PC with **Windows 8**, proceed directly to step 2


2. Right click on the **Start menu** (Windows Logo)




3. Click on **Network Connections**




4. Right click on **Ethernet Connection** for the adapter (it may state **ETHERNET 2**)



5. Click on **Properties**




6. Click on internet protocol **Ver. 4**
TCP/IP 4



7. Then click on **Properties**

8. Click **Use the following IP address:**



☐ Obtain an IP address automatically
☒ Use the following IP address:
 IP address:
 Subnet mask:
 Default gateway:

9. Enter the IP address of the instrument here, but make the last number in the IP address **at least 1 number higher** than the instrument.




☒ Use the following IP address:
 IP address:
 Subnet mask:
 Default gateway:

10. Click in the Subnet Mask box and enter 255.255.255.0 as shown.




☒ Use the following IP address:
 IP address:
 Subnet mask:
 Default gateway:

11. Click in the Default Gateway box and enter 192.168.100.001 as shown.



☒ Use the following IP address:
 IP address:
 Subnet mask:
 Default gateway:

12. Click in the Preferred DNS server box and enter 008.008.008.008 as shown.




☒ Use the following DNS server addresses:
 Preferred DNS server:
 Alternate DNS server:

13. Click **OK** close this window.

14. Connect your PC or Tablet to the instrument using the ethernet cable.

15. Open your browser (Internet Explorer, Chrome or FireFox)

16. Enter the IP address of the instrument in the browser address bar



WHEN USING CERTAIN BROWSERS, YOU MAY NEED TO INCLUDE LEADING ZEROS WHEN ENTERING THE IP ADDRESS.



FAIRBANKS SCALES, INC.
www.fairbanks.com

FB6000 Series Instrumentation

FB6001 IN/OUT/GTN Analog Desktop Instrument

FB6002 IN/OUT/GTN Analog NEMA 4X Wall mount Instrument

FB6003 In/Out/GTN Analog Panel Mount Instrument

Operator Manual 51293