

# FAIRBANKS®

## RICE LAKE JUNCTION BOX INTALOGIX® CONVERSION KIT



*Intalogix® Conversion Kits for Rice Lake analog truck or rail scales, come with four or five Smart Sectional Controllers that install directly into the scale's existing junction box.*

### KITS ENABLE ANALOG TO DIGITAL CONVERSION

Fairbanks has engineered unique Intalogix® conversion kits made to easily convert Rice Lake scales with analog load cells to Fairbanks' premier digital load cell communication technology. The 4- or 5-section kits arrive fully assembled and ready to install into an existing Rice Lake junction box.

### FEATURES


- Aluminum bracket for installation into Rice Lake junction box
- Pre-wired Pit Power Supply and Smart Sectional Controllers
- Smart Sectional Controllers swivel out of enclosure for easy access
- Extended sensing range
- Diagnostic capabilities and accuracy of Intalogix® Technology

### SPECIFICATIONS


Number of load sections . . . . . 4 or 5  
Number of load cells  
Four sections . . . . . Up to 8  
Five sections . . . . . Up to 10  
Dimensions (no enclosure) . . . 8.75" x 7.50" x 4.61"

### DIMENSIONS

**5 SECTION  
CONVERSION  
KIT**



**4 SECTION  
CONVERSION  
KIT**



### QuickFacts™

Models and specifications subject to change without notice.  
Printed in the USA. © Fairbanks Scales Inc.

Call toll-free for the Fairbanks representative nearest you:

**(800) 451-4107**

Internet address: <http://www.Fairbanks.com>